

SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table



SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table Installation Guide

[Home](#) » [SPRING GARDEN](#) » [SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table Installation Guide](#) 

Contents

- [1 SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 ASSEMBLY INSTRUCTION](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table



Product Information

Specifications:

- Installation time: 60 minutes
- Maximum weight capacity: 240kg

Product Usage Instructions

Assembly Instructions

Before starting the assembly process, ensure you have all the components listed in the manual.

Step 1

Begin by assembling parts B-1 to B-3 as shown in the manual.

Step 2 (Using rubber ring)

Attach parts B-4 to B-6 using the provided rubber rings and screws. Do not tighten the screws completely at this stage.

Step 3 (Using rubber ring)

Continue assembling parts following the instructions provided.
Use the rubber rings where specified.

Step 4 to Step 8

Follow the manual for each step, ensuring you do not tighten any screws completely until the assembly is fully completed.

Frequently Asked Questions (FAQ)

1. **Q: Can I exceed the maximum weight capacity of 240kg?**

A: It is not recommended to exceed the maximum weight capacity for safety reasons.


2. Q: What should I do if I miss any components during assembly?

A: Contact customer support to order any missing parts before proceeding with assembly.

3. Q: Are additional tools required for assembly?

A: The assembly manual lists all tools required for the process.

Make sure you have them before starting assembly.




ASSEMBLY INSTRUCTION


	B-1 (1pc)	B-2 (1pc)	B-3 (1pc)	B-4 (1pc)
Pic				
	B-5 (1pc)	B-6 (1pc)	B-7 (1pc)	B-8 (2pcs)
Pic				
	B-9 (4pcs)	Wrench M6 (1pc)	Allen Key M6 (1pc)	Washer M6 (28pcs)
Pic		Wrench M8 (1pc)	Allen Key M8 (1pc)	Washer M8 (8pcs)
	M6x35 Screw(8pcs)	M6x15 Screw(8pcs)	Nut M6 (8pcs)	rubber ring (8pcs)
Pic	M6x20 Screw(4pcs)	M8x40 Screw(2pcs)	Nut M8 (6pcs)	

DO NOT tighten any screws before assemble completely .

Step 1




Step 2 (Using rubber ring)




DO NOT tighten any screws before assemble completely .


Step 3 (Using rubber ring)




Step 4




Step 5




Step 6 (Using rubber ring)



Step 7



Step 8



Documents / Resources



[SPRING GARDEN PRE ORDER Reclining Armchair With Flip Table](#) [pdf] Installation Guide C7, C8, C9, PRE ORDER Reclining Armchair With Flip Table, PRE ORDER, Reclining Armchair With Flip Table, Armchair With Flip Table, Flip Table, Table

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.