

**STAR  
WARS**

E0584  
CHEWIE  
INTERACTIVE  
PLUSH  
TOY



# Star Wars E0584 Chewie Interactive Plush Toy User Manual

[Home](#) » [STAR WARS](#) » Star Wars E0584 Chewie Interactive Plush Toy User Manual 

## Contents

- [1 Star Wars E0584 Chewie Interactive Plush Toy](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)
- [13 Related Posts](#)

**STAR  
WARS**

**Star Wars E0584 Chewie Interactive Plush Toy**



## INTRODUCTION

You can go on an intergalactic trip with the “Star Wars E0584 Chewie Interactive Plush Toy,” a beautifully made animatronic of Chewbacca, everyone’s favorite Wookiee. This high-end toy costs \$59.99 and is made for Star Wars fans and collectors. It was made by Hasbro, a big name in the toy business, and Chewie is over 16 inches tall. It makes sounds and moves just like the popular character from the movies. This plush toy, which came out in 2023, uses cutting-edge technology to respond to both speech and touch. This makes Chewie a responsive friend for both play and display. This interactive plush is great for kids ages 4 and up. It encourages imaginative play and brings the excitement of the Star Wars world right into your living room.

## SPECIFICATIONS

Brand Name	STAR WARS
Model Name	Animatronic Plush
Model Number	E0584
Item Weight	1.6 Kilograms
Item Dimensions (L x W x H)	14.17 L x 5.91 W x 16.93 H Inches
Unit Count	1.0 Count
Manufacturer Minimum Age	48 months
Number of Batteries	4 AA batteries required
Special Features	Sound
Price	\$59.99

## WHAT'S IN THE BOX

- Chewie Interactive Plush Toy
- Battery
- Manual

## FEATURES

- **Interactive Plush Toy:** The Ultimate Co-Pilot Chewie is made to keep kids' attention through interactive play, which makes it a great toy for making up stories.
- **Sound and Movement Combinations:** Chewie responds to different moves and interactions with more than 100 different sound and movement combinations.
- **Wookiee Language Responses:** When kids talk to Chewie, he answers in the famous Wookiee language, which makes them feel like they are really in the Star Wars world.
- **looks on the Face:** The toy has funny looks on its face that make it more interactive and real-looking.
- **Arm-Raising Roars:** Chewie can make arm-raising roars to sound like his movie character and make play more exciting.
- **Snores Every Once in a While:** The plush toy can also snores, which helps it look more like the popular character.
- The accessories that come with Chewie are a bandolier and a backpack, just like in the movies.
- **Designed for Kids Ages 4 and Up:** This is a great gift for young Star Wars fans because it is made for kids ages 4 and up.
- **Durable Construction:** It was made with high-quality materials that will last and hold up well during play.
- **Lightweight:** It only weighs 1.6 kilograms, which makes it easy for kids to play with and take around.

- It's small—about 14.17 inches tall, 5.91 inches wide, and 16.93 inches long—so it's great for hugging.
- **Battery Operated:** Needs 4 AA batteries, which are not included. This makes it portable and easy to use without being plugged in.
- **Interactive Features:** The soft toy comes to life thanks to its animatronic features, which make it more fun for kids to play with.
- **Encourages Creativity:** Lets kids make up their own Star Wars experiences, which promotes imaginative play.
- **Officially approved:** This is an approved Star Wars item that captures the spirit of the character and is good for both collectors and fans.

## SETUP GUIDE

- **Unpack the Toy:** Take Chewie out of the box slowly so you don't break any of the parts.
- **Install Batteries:** Use a screwdriver to open the battery box, which is usually on the back of the toy.
- **Insert Batteries:** Carefully place four AA batteries into the compartment, making sure they are positioned so that the positive (+) and negative (-) signs point in the right direction.
- **Close Battery Compartment:** Make sure the battery compartment is closed tightly so the cells don't fall out.
- To turn on the toy, find the power switch and flip it on. The switch is usually near the battery box.
- **Sound and Motion:** To use the sound and motion functions, press or move Chewie.
- You can talk to Chewie and hear his answers in Wookiee's tongue. This is an interactive game that you can enjoy.
- **Explore Functions:** Try out different features to see how Chewie reacts, such as roars and snores that raise the arms.
- **Engage in Imaginative Play:** Tell kids to make up their own stories and adventures with Chewie.
- **Watch Kids Play:** Always keep an eye on younger kids while they play to make sure they stay safe.
- **Safely Store:** Keep Chewie in a safe place when not in use to keep him from getting broken.
- **Check Batteries Often:** Keep an eye on the battery levels and change them as needed to make sure they always work.
- **Engage with Other Star Wars Toys:** For more dynamic fun, play with other Star Wars toys at the same time.
- **Show Features:** For the most fun, show kids how to make different sounds and moves happen.
- Take part in family fun by interacting with Chewie at the same time.

## CARE & MAINTENANCE

- **Regular Checks:** To make sure Chewie is safe for play, check him often for any signs of damage or wear.
- **Keep Clean:** To keep the plush outside clean, wipe it down with a damp cloth instead of harsh chemicals.
- **Do Not Wash:** Because Chewie has electrical parts, do not put him in water or wash him in a machine.
- **Check the Battery Levels:** If the sound quality gets worse or the toy stops responding, replace the batteries right away.
- **Handling with Care:** To make Chewie last longer, teach kids how to play with him gently.
- **Do Not Drop:** Do not drop the toy to keep the internal parts from getting damaged.
- Keep Chewie in a dry place to keep him from getting damaged by water.
- If you're going to be keeping something for a long time, take out the batteries to keep them from leaking.
- **Inspect for open Parts:** Make sure there aren't any open parts that could cause someone to choke on them on a regular basis.

- **Avoid Direct Sunlight:** Keep things out of direct sunlight to keep colors and materials from fading.
- If you need to, use a soft brush to fluff up the fluffy stuff to keep it looking new.
- **Quick Repairs:** Take care of any problems right away, like sounds or moves that don't work.
- **Teach Children to Respect the Toy:** Teach kids that they need to take care of their toys.
- **Check the Battery box:** Make sure the battery box is completely closed to avoid any damage.

TROUBLESHOOTING

Issue	Solution
The toy does not make sounds	Check and replace the AA batteries.
Movements are stiff or halted	Ensure no obstructions in the joints.
Sounds are distorted	Replace batteries or check the speaker for blockages.
The toy does not respond to touch	Confirm that sensors are not covered or dirty.
Fabric tears	Repair minor tears; avoid rough handling.
Battery compartment issues	Ensure proper battery installation and secure the compartment.
Unexpected shutdowns	Replace with new batteries; check for overheating.
Toy becomes unresponsive	Reset the toy by removing and reinstalling the batteries.
Chewbacca's roar is too low	Adjust the volume if available or check the battery level.
Sensor malfunction	Clean the sensors gently with a soft cloth.
LED indicators not working	Check LEDs for functionality or replace batteries.
Mechanical noise during operation	Lubricate the joints if accessible or contact Hasbro for support.
Continuous operation without triggering	Turn off and restart to reset the electronic system.
Toy emits a burning smell	Stop use immediately and check internal electronics.
Difficulty activating features	Ensure the activation button is functional and accessible.

PROS & CONS

PROS:

1. **Authentic Sounds:** Features original Chewbacca roars and growls for an authentic experience.
2. **Responsive Interaction:** Reacts to sound and touch with movements and noises.
3. **High-Quality Materials:** Constructed with soft yet durable materials suitable for cuddling and play.
4. **Collectible Item:** A must-have for Star Wars collectors and enthusiasts.
5. **Encourages Imagination:** Stimulates creative play and storytelling among fans of all ages.

CONS:

1. **Price Point:** A higher price tag might be prohibitive for casual buyers.
2. **Battery Consumption:** Requires frequent battery changes due to advanced animatronic features.

3. **Size and Weight:** May be too large and heavy for younger children to carry easily.
4. **Maintenance:** Requires careful handling to maintain electronic components.
5. **Noise Level:** The sounds can be loud, which might not be suitable for quieter play environments.

## WARRANTY

The Star Wars E0584 Chewie Interactive Plush Toy comes with a **1-year limited warranty** from Hasbro. This warranty covers defects in materials and workmanship under normal use, ensuring that your Chewbacca remains a reliable and functional part of your Star Wars collection.

## FREQUENTLY ASKED QUESTIONS

What is the Star Wars E0584 Chewie Interactive Plush Toy?

The Star Wars E0584 Chewie Interactive Plush Toy is an animatronic plush designed to engage children with sounds and movements, bringing the beloved character Chewbacca to life.

What is the price of the Star Wars E0584?

The Star Wars E0584 Chewie Interactive Plush Toy is priced at \$59.99, making it a premium collectible for Star Wars fans.

What are the dimensions of the Star Wars E0584?

The dimensions of the Star Wars E0584 are 14.17 inches in length, 5.91 inches in width, and 16.93 inches in height.

How much does the Star Wars E0584 weigh?

The Star Wars E0584 weighs 1.6 kilograms (approximately 3.53 pounds), providing a sturdy and substantial feel for children.

What is the minimum age recommendation for the Star Wars E0584?

The manufacturer recommends the Star Wars E0584 for children aged 48 months (4 years) and older.

What type of batteries does the Star Wars E0584 require?

The Star Wars E0584 requires 4 AA batteries for its sound and interactive features to function.

Are batteries included with the Star Wars E0584?

Typically, the batteries are not included with the Star Wars E0584, so you will need to purchase 4 AA batteries separately.

What special features does the Star Wars E0584 have?

The Star Wars E0584 features sound capabilities, allowing it to produce various sounds associated with Chewbacca, enhancing the interactive experience.

What types of sounds does the Star Wars E0584 produce?

The Star Wars E0584 typically emits iconic Chewbacca sounds and phrases that fans of the franchise will recognize.

What materials are used in the construction of the Star Wars E0584?

The Star Wars E0584 is made from soft plush materials, ensuring it is safe and comfortable for children to cuddle.

Is the Star Wars E0584 suitable for outdoor play?

While it can be used outdoors, it's best to keep the Star Wars E0584 away from moisture and dirt to maintain its quality and functionality.

How does the sound activation work on the Star Wars E0584?

The sound feature is typically activated by pressing a button or interacting with the plush toy, prompting it to make sounds or phrases.

What makes the Star Wars E0584 a great gift for children?

The combination of its interactive features, iconic character design, and high-quality plush material makes the Star Wars E0584 an exciting and appealing gift for young fans.

How does the Star Wars E0584 enhance playtime for children?

The engaging sounds and interactive nature encourage imaginative play, allowing children to create their own Star Wars adventures with Chewbacca.

What educational benefits does the Star Wars E0584 provide?

The Star Wars E0584 helps promote imaginative play, encourages storytelling, and allows children to engage with their favorite characters, enhancing their creative development.

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.