



## Starfrit 93774 High Precision Scale Instruction Manual

[Home](#) » [Starfrit](#) » Starfrit 93774 High Precision Scale Instruction Manual 

### Starfrit 93774 High Precision Scale Instruction Manual




## Contents

- 1 SPECIFICATIONS
- 2 BATTERIES
- 3 TO REPLACE BATTERIES
- 4 LCD SCREEN
- 5 BUTTONS
- 6 WEIGHING MODE
- 7 UNIT CONVERSION
- 8 TARE FUNCTION
- 9 AUTO SHUT OFF & MANUALLY SHUT OFF
- 10 INDICATORS
- 11 ADVICE FOR USE & CARE
- 12 Documents / Resources
  - 12.1 References
- 13 Related Posts

## SPECIFICATIONS

- High precision strain gauge sensor
- Stainless steel weighing platform
- **Units of measure include:** grams (g), ounces (oz), carats (ct), grains (gn), Troy ounces (ozt), Tael (tl) and Pennyweight (dwt)
- Tare function
- Low battery and overload indicators
- Auto-off after three minutes or manual-off
- **Capacity:** 7 oz / 200 g
- **Accuracy:** 0.001 oz / 0.01 g
- **Platform dimensions:** 3" x 2.5" / 76 mm x 64.6 mm
- **Blue backlight LCD screen dimensions:** 0.9" x 0.4" / 23.8 mm x 11 mm

## BATTERIES




- Requires 2 AAA batteries (included).
- Remove isolation sheet before use.

## TO REPLACE BATTERIES

- Open battery case cover underneath the scale.
- Take out the used batteries and install new ones.  
Make sure to respect the polarity.
- Close battery case cover.

## LCD SCREEN



## BUTTONS



Tare function




Mode and unit conversion



Turn ON Turn OFF

## WEIGHING MODE



- Place the scale on a solid and flat surface.




- Press button to turn on the scale.
- Wait until LCD screen shows “0.0” to start weighing.



- Press button to convert to weight mode if needed.
- Load weighing object on scale.

Always place the object in the center of the platform. LCD screen will show the weight reading.

## UNIT CONVERSION



- Press button to switch the weight measure.

## TARE FUNCTION

To weigh different loads consecutively without removing loads from the scale, put the first load on the scale to



obtain a weight reading. Press button to reset the LCD reading to “0.00” before adding next load. You can repeat operation.

## AUTO SHUT OFF & MANUALLY SHUT OFF



Auto shut off occurs if display shows "0" or shows the same weight reading for 3 minutes.

To maximize battery life, it is recommended to shut off manually the scale. Press



button for 3 seconds and the scale will turn off.

## INDICATORS

1. Please replace batteries.



2. Remove item to avoid damage.

Maximum capacity of this scale is 7 oz / 200 g.



3. Place the scale on a flat and stable position.



## ADVICE FOR USE & CARE

- Always use the scale on a hard flat surface.
- Clean the scale with a slightly damp cloth.

- Avoid contact with water. DO NOT immerse the scale in water.
- All plastic parts should be cleaned immediately after contact with fat, spices, vinegar and strongly flavored /colored food.
- Avoid contact with acid citrus juices.
- DO NOT use chemical or abrasive cleaning agents.
- Not for commercial use.

SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS!

[www. Starfrit.COM](http://www.Starfrit.COM)




[www.facebook.com/starfrit](http://www.facebook.com/starfrit)



PRINTED IN CHINA FOR: ATLANTIC PROMOTIONS INC. LONGUEUIL (QUÉBEC) J4G 1V6  
CUSTOMER SERVICE: STARFRIT COM/EN/CONTACT-US

# Starfrit

## Documents / Resources

	<p><a href="#">Starfrit 93774 High Precision Scale</a> [pdf] Instruction Manual 93774, 93774 High Precision Scale, 93774, High Precision Scale, Precision Scale, Scale</p>
---	--

## References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.