



STARMAX WM-WSPHRT-NGRN Bluetooth Speaker Instruction Manual

[Home](#) » [Starmax](#) » STARMAX WM-WSPHRT-NGRN Bluetooth Speaker Instruction Manual 



Instruction Manual
Model: WM-WSPHRT-NGRN


Contents

- 1 Specification:
- 2 Device description
- 3 Power on and connect
- 4 Cleaning and storage
- 5 Documents / Resources
 - 5.1 References

Specification:

Bluetooth 5.3
Charging time: 150 min
Music playing time: 60-90 min
Material: ABS

Device description



1. On/off Switch
2. LED indicators
3. Charging port

Power on and connect

Switch the on/off button on the device to turn the speaker on or off. Enable function on mobile device, and search for devices.

The device name is "WM-WSPHRT". When the Bluetooth® Bluetooth® pairing is successful, a beep will sound. If you want to switch pairing to other mobile devices, then you need to cut off the connection of existing equipment and repeat the steps with the new device.

WARNING:

You must select a qualified charger from a reliable source.

You must charge the Bluetooth® speaker if it has not been used for more than 12 months.

Please fully charge the device for 3-4 hours before first use. Connect the cable to the computer's USB port, use an AC adapter (not included) or other DC power supply not exceeding 5V, 0.3A.

The LED indicator will light up and the LED indicator will turn off when the speaker is fully charged.

Cleaning and storage

1. Turn off the device before cleaning.
2. Use a soft damp cloth for cleaning.
3. Do not use corrosive cleaners or abrasives (such as steel wool or brushes) for cleaning.

Disposal of Batteries (if applicable):

Never dispose of any types of batteries in fire or near excessive heat or direct sunlight. Overheated batteries can rupture or explode.

If you are unsure of how or where to dispose of a battery, refer to your local ordinances for the proper location, method, etc.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment.

Distributed by:



Documents / Resources

	STARMAX WM-WSPHRT-NGRN Bluetooth Speaker [pdf] Instruction Manual WM-WSPHRT-NGRN Bluetooth Speaker, WM-WSPHRT-NGRN, Bluetooth Speaker, Speaker
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.