



StarTech.com CABSHELFV2U Vented Server Rack Shelf User Guide

[Home](#) » [StarTech.com](#) » StarTech.com CABSHELFV2U Vented Server Rack Shelf User Guide 

StarTech.com

Hard-to-find made easy®
Quick-Start Guide


Contents

- [1 Vented 2-Post Shelf](#)
- [2 Package Contents](#)
- [3 Installation](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

Vented 2-Post Shelf

Product ID

CABSHELFV2U-16-RACK
CABSHELFV2U-12-RACK
CABSHELFV1U-16-RACK



*Product may vary from image

	Feature	Function
1	Front Mounting Brackets	Used to fasten the Shelf to the Mounting Posts of a Server Rack
2	Shelf Surface	Place Server Rack Equipment
3	Ventilation Holes	Promote airflow for the Server Rack Equipment

Package Contents

- 2-Post Vented Shelf x1
- M5 Cage Nuts x 4
- M5 Screws x 4
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit:

www.StarTech.com/CABSHELFV2U-16-RACK

www.StarTech.com/CABSHELFV2U-12-RACK

www.StarTech.com/CABSHELFV1U-16-RACK

- Refer to the manufacturer of the Server Rack to determine the mounting hole type and size
- Phillips head screwdriver
- Cage nut tool (Optional)

Warnings!

- Read the entire Quick-Start Guide and ensure the instructions are fully understood before using this product.
- Before adding equipment to this product, ensure this product has been properly mounted.
- Never operate this product if parts are missing or damaged.
- Ensure the weight of the equipment does not exceed the weight capacity of this product. If the weight capacity is exceeded, personal injury or damage to the equipment is possible.
- These product can support the following weight:
- CABSHELFV2U-16-RACK: 44lb / 20kg
- CABSHELFV2U-12-RACK: 25lb / 11.3 kg
- CABSHELFV1U-16-RACK: 30lb / 14kg

Installation

1. Identify a suitable location on the Server Rack to mount the Shelf. The Shelf requires 2U or 1U of Mounting Space (depending on the model).
Note: The Server Rack should have enough Mounting Depth to accommodate the Shelf.
2. Install the M5 Cage Nuts (x 4) into the Mounting Holes (x 4) on the Front Posts of the Server Rack. If available, use a Cage Nut Tool or a preferred installation method to install the Cage Nuts.
Note: If the Server Rack has M5 threaded holes, skip this step. The M5 Screws can be installed without the M5 Cage Nuts.
Use the manufacturer-recommended Screws for the Server Rack if they differ from M5.
3. Position the Shelf onto the Server Rack at the chosen U Height, determined in Step 1, with the Front Mounting Brackets facing forward. Ensure the Holes (x 4) on the Front Mounting Brackets are Aligned with the Mounting Holes on the Front Posts of the Server Rack.
4. Insert the M5 Screws (x 4) through the Front Mounting Brackets and into the M5 Cage Nuts (x 4). Tighten the M5 Screws (x 4) using a Phillips Head Screwdriver.
Note: Ensure the Shelf is secure before placing Server Rack Equipment.

Regulatory Compliance

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders

Warranty Information

This product is backed by a lifetime warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

StarTech.com Ltd. 45 Artisans Crescent London, Ontario N5V 5E9 Canada	StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.	StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Road Brackmills, Northampton NN4 7BW United Kingdom	StarTech.com Ltd. Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands	FR: st DE: st ES: st NL: st IT: sta JP: st
---	---	--	--	---


StarTech.com

Hard-to-find made easy®

For additional self-service support
options and community forums, please
visit: www.StarTech.com/support

Revision: August 29, 2024

Documents / Resources



[StarTech.com CABSHELFV2U Vented Server Rack Shelf](#) [pdf] User Guide
CABSHELFV2U-16-RACK, CABSHELFV2U-12-RACK, CABSHELFV1U-16-RACK, CABSHELF
V2U Vented Server Rack Shelf, CABSHELFV2U, Vented Server Rack Shelf, Server Rack Shelf,
Rack Shelf

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.