



StarTech com M3013 Anti-Static Mat User Guide

[Home](#) » [StarTech.com](#) » StarTech com M3013 Anti-Static Mat User Guide



Quick-Start Guide

Anti-Static Mat

Product IDs

SM-ANTI-STATIC-MAT – 11.8 in x 18 in (30 cm x 46 cm)

M3013 23.6 in x 27.5 in – (60 cm x 70 cm)

LG-ANTI-STATIC-MAT – 23.6 in x 47.2 in (60 cm x 120 cm)

Contents [[hide](#)

- [1 Product Diagram](#)
- [2 Package Contents](#)
- [3 Requirements](#)
- [4 Installation](#)
- [5 Regulatory Compliance](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Product Diagram



	Component	Function
1	Anti-Static Mat	• Prevent ESD damage to sensitive hardware that is placed on top of the Anti-Static Mat.
2	Grounding Point	• Grounding Wire connection point.
3	Grounding Wire With Alligator Clip	• Connects to the designated Common Grounding Point of the work area. Warnings! Not meant to be used with a Wrist Strap. Not meant to be connected to another Anti-Static Mat. There should be only one Grounding Point to the Anti-Static Mat.

Package Contents

- Anti-Static Mat x 1
- Grounding Wire With Alligator Clip x 1
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit the corresponding product link:

www.startech.com/SM-ANTI-STATIC-MAT

www.startech.com/M3013

www.startech.com/LG-ANTI-STATIC-MAT

- Clean, dry, and flat surface

Installation

1. Unroll the Anti-Static Mat in the work area. Allow the Anti-Static Mat to completely flatten out at room temperature.
2. Determine where the Common Grounding Point is located in the work area. Ensure the Common Grounding Point is bare metal and free of paint or any other insulating material.
3. Connect the Grounding Wire With Alligator Clip to the Grounding Point, located on the corner on the Anti-Static Mat.

4. Clip the Grounding Wire with Alligator Clip onto the designated Common Grounding Point.

Regulatory Compliance

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of thirdparty companies not related in any way to [StarTech.com](#). Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by [StarTech.com](#), or an endorsement of the product(s) to which this manual applies by the third-party company in question. [StarTech.com](#) hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Warranty Information

This product is backed by a two-year warranty.
For further information on product warranty terms and conditions, please refer to [www.startech.com/warranty](#).

Limitation of Liability

In no event shall the liability of [StarTech.com](#) Ltd. and [StarTech.com](#) USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

- Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

StarTech.com Ltd. 45 Artisans Crescent London, Ontario N5V 5E9 Canada	StarTech.com Ltd. 4490 South Grove 4 l
StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Road Brackmills, Northampton NN4 7BW United Kingdom	StarTech.com Ltd. Sirius 2132 W The N

To view manuals, FAQs, videos, drivers, downloads, technical drawings, and more, visit [www.startech.com/support](#)

Documents / Resources

	StarTech.com M3013 Anti-Static Mat [pdf] User Guide M3013, Anti-Static Mat, M3013 Anti-Static Mat, Mat
---	---

References

- [!\[\]\(a22ba4e13c745edbf29e51af246c4c12_img.jpg\) StarTech.com | IT Pro's Trusted Source for Connectivity Accessories](#)
- [!\[\]\(33b18af9a4b997eb52666cfeb3c44157_img.jpg\) Anti Static Mat, ESD Mat For Desk/Table - Anti-Static Products | StarTech.com](#)
- [!\[\]\(262b158440b847a82f89a14cab8644ec_img.jpg\) 24x27.5in Beige Desktop Anti-Static Mat - Anti-Static Products | StarTech.com](#)
- [!\[\]\(f51929fecf7b0dc947ac13f4c4835e8f_img.jpg\) Anti Static Mat, ESD Mat For Desk/Table - Anti-Static Products | StarTech.com](#)
- [!\[\]\(dfbf0e54bcca114319aa65c906feb8d0_img.jpg\) StarTech.com Support](#)
- [!\[\]\(64792950f1b7ee883a860b5f0af110c3_img.jpg\) StarTech.com Warranty Policy](#)