

StarTech com PEX2PCI4 PCI Express to 4 Slot PCI Expansion **System User Guide**

Home » StarTech com » StarTech com PEX2PCI4 PCI Express to 4 Slot PCI Expansion System User Guide 🖺



Contents

- 1 StarTech com PEX2PCI4 PCI Express to 4 Slot PCI Expansion **System**
- 2 Package Contents
- 3 Requirements
- 4 Installation
- **5 Warranty Information**
- 6 Limitation of Liability
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**



StarTech com PEX2PCI4 PCI Express to 4 Slot PCI Expansion System



PCI Express to 4 Slot PCI Expansion System



Front



	Port/LED/ Connector	Function
		Turns the Expansion Chassis On or Off
		Correct sequence to power the device:
1	On/Off Switch	Power on: Power On the PCI Expansion Chassis first, then the Host Computer
		Power off: Power Off the Host Computer first, then the PCI Expansion C hassis
		Connect the PCI Expansion Chassis to a Power Source
2	DC Power Port	using the included Power Adapter
		Recommended 12 V and 3 A
		Used to connect the PCI Expansion Chassis to a Host Computer
		If the DVI Cable is disconnected during use, the Host Computer must be restarted to reestablish the connection
3	DVI Connector	For a secure cable connection, threaded holes around the DVI Connector allow to Screw-lock the included DVI Cable
		Indicates if the On/Off Switch is turned On or Off
4	Power LED Indicator	Solid Red = On
4		• Off = Off
5	Metal Cover Screws	Remove the Metal Cover Screws to release the Metal Cover and install PCI cards
6	PCI Expansion Slots	Install up to Four PCI cards
		(Optional) Allows for a permanent installation of the PCI Expansion Chas sis to a flat and stable surface
7	Mounting Brackets Points	Mounting Holes at the Front and Back of the PCI Expansion Chassis s ecure the Mounting Brackets

Package Contents

- PCI Expansion Box x 1
- PCI Express Card
- 3ft DVI cable x 1
- Low-Profile Bracket x 1
- Screw Kit x 1
- Power Adapter x 1
- Quick-Start Guide x 1

Requirements

For the latest requirements, please visit www.startech.com/PEX2PCI4

- Host computer with an available PCle slot (x1, x2, x4, x8, or x16)
- Phillips head screwdriver

Installation

WARNING: Static electricity can severely damage the PCle card(s) ensure that you are adequately grounded before you open your Host Computer case or touch the PCle card(s). You should wear an anti-static strap or use an anti-static mat when installing any Host Computer component. If an anti-static strap isn't available, discharge any built-up static electricity by touching a large grounded metal surface for several seconds. Only handle the PCle card(s) by the edges and don't touch the golden connectors.

Install the PCIe Host Adapter Card

- 1. Turn Off the Host Host Computer and any Peripheral Devices that are connected to it (e.g. printers, external hard drives, etc.).
- 2. Unplug the Power Cable from the back of the Host Computer.
- 3. Disconnect any Peripheral Devices that are connected to the Host Computer.
- 4. Remove the Cover from the Host Computer Case. Consult the documentation that came with the Host Computer for details about doing this safely.
- 5. Locate an available PCIe Slot and remove the corresponding Slot Cover Plate from the back of the Host Computer Case. Consult the documentation that came with the Host Computer for details about doing this safely. The PCIe Host Adapter Card works in PCIe x1, x2, x4, x8, or x16 Slots.
- 6. Gently insert the PCIe Host Adapter Card into the PCIe Express Slot and fasten the Bracket to the back of the Host Computer Case.

Note: If you install the PCIe Host Adapter Card into a small form factor or a low-profile desktop system, it may be necessary to replace the pre-installed standard full-height bracket with the included low-profile bracket.

- 7. Return the Cover onto the Host Computer Case.
- 8. Reconnect the Power Cable to the back of the Host Computer.
- 9. Reconnect all of the Peripheral Devices disconnected in Step 1.

Install PCI Cards in the PCI Expansion Chassis

Sharp edges! Be mindful of the sharp edges around the PCIe Expansion Chassis when the Metal Cover is removed.

- 1. Turn Off the PCI Expansion Chassis and unplug all cable connections.
- 2. Release the Metal Cover by removing the Screws (x 10) using a Phillips Head Screwdriver. The Screws are located on top and the opposite side of the connectors on the PCI Expansion Chassis.
- 3. Locate an available PCI Slot on the Expansion Chassis, using a Phillips Head Screwdriver remove the corresponding Slot Cover Plate from the PCI Expansion Chassis.
- 4. Gently insert the PCI Card (s) into the PCI Slot and fasten the Bracket to the PCI Expansion Chassis.
- 5. Install the Metal Cover back onto the PCI Expansion Chassis.
- 6. Screw-Lock the DVI Cable on the DVI Connector of the PCI Expansion Chassis and onto the PCIe Host Adapter Card.

- 7. Connect the Power Adapter to supply power. Turn On the Expansion Chassis by flipping the On/Off Switch.
- 8. Turn On the Host Computer.

Note: No drivers are needed for the PCI Expansion Chassis. Some PCI Cards may need drivers to finish their installation.

(Optional) Install the Mounting Brackets

- 1. Use the Mounting Screws (x 2) and Phillips Head Screwdriver to fasten the Front Mounting Bracket on the PCIe Expansion Chassis.
- 2. Repeat Step 1 to install the Rear Mounting Bracket.

Regulatory Compliance

FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used

in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference
- 2. This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference,
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Warranty Information

This product is backed by a two years warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

• Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

Contact

• StarTech.com Ltd.

Address: 45 Artisans Crescent London, Ontario N5V 5E9 Canada

· StarTech.com Ltd.

Address: Unit B, Pinnacle 15 Gowerton Road Brackmills, Northampton NN4 7BW United Kingdom

StarTech.com LLP

Address: 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.

StarTech.com Ltd.

Address: Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands

StarTech.com

Documents / Resources



StarTech com PEX2PCI4 PCI Express to 4 Slot PCI Expansion System [pdf] User Guide PEX2PCI4, PCI Express to 4 Slot PCI Expansion System, 4 Slot PCI Expansion System, PCI Expansion System, Expansion System

References

- StarTech.com | IT Pro's Trusted Source for Connectivity Accessories
- Order to 4 Slot PCI Expansion System Slot Conversion & Slot Extension | StarTech.com
- StarTech.com Support
- StarTech.com Warranty Policy
- Y You | Fabricant de cuisines aménagées & salles de bains sur-mesure

Manuals+,