

StarTech com ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card User Guide

Home » StarTech com » StarTech com ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card User Guide ™



Hard-to-find made easy® Quick-Start Guide


Contents

- 1 ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card
- 2 Product Diagram (ST10GSPEXNDP2)
- **3 Package Contents**
- 4 Installation
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**

ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card

2-Port 10GBase-T / NBase-T Ethernet Network Adapter Card – PCle Ver 3.0 x4

Product Diagram (ST10GSPEXNDP2)



Port/LED/Connector		Function
1	Bracket	Secures the card to the Computer Case The Full-Height Bracket comes pre-installed The Low-Profile Bracket is included
2	2x Ethernet Ports	Connect a Network Cable to the Network Card Supports 10 Gbps/S Gbps/2.S Gbps/1 Gbps/100 Mbps/10 Mbps For 10 Gbps speeds Cat6 or higher cable is needed
3	LED Indicators	 Left LED Indicator is Link Speed Solid Green = 10 Gbps Solid Amber = 5 Gbps/2.S Gbps/1 Gbps/100 Mbps/10 Mbps Right LED Ind icator is Link Status Solid Green = Active link Flashing Green = Activity
4	PCIe x4 Connector	Insert into a PCI Express Slot on the Host Computer

Package Contents

- PCle 10 Gbps Network Card x 1
- Low-profile Bracket x 1
- Quick-Start Guide x 1

Requirements

For the latest requirements, please visit www.startech.com/ST10GSPEXNDP2

• Computer with an available PCI Express Slot (x4, x8, or x16)

Installation

Install the PCI Express Card

WARNING!

Static Electricity can severely damage PCI Express Cards. Ensure that you are adequately Grounded before you open your Computer Case or touch the PCI Express Card. You should wear an Anti-Static Strap or use an Anti-Static Mat when installing any computer component. If an Anti-Static Strap isn't available, discharge any built-up static electricity by touching a large Grounded Metal Surface for several seconds. Only handle the PCI Express Card by its edges and don't touch the gold connectors.

- 1. Turn off the **Computer** and any **Peripheral Devices** that are connected to it (for example, **Printers, External Hard Drives, etc.**).
- 2. Unplug the Power Cable from the back of the Computer.
- 3. Disconnect any Peripheral Devices that are connected to the Computer.
- 4. Remove the **Cover** from the **Computer Case**. Consult the documentation that came with the **Computer** for details about doing this safely.
- 5. Locate an open PCI Express Slot and remove the corresponding Slot Cover Plate from the back of the Computer Case. Consult the documentation that came with the Computer for details about doing this safely. This card works in PCI Express x4, x8, or x16 Slots.
- 6. Gently insert the **PCI Express Card** into the open **PCI Express Slot** and fasten the Bracket to the back of the **Computer Case**.

Note: If you install the PCI Express Card into a Small Form Factor or a Low-Profile Desktop System, it may be necessary to replace the pre-installed standard Full-Height Bracket with the included Low-Profile Bracket.

- 7. Return the **Cover** onto the **Computer Case**.
- 8. Reconnect the **Power Cable** to the back of the **Computer.**
- 9. Reconnect all of the Peripheral Devices disconnected in Step 2.
- 10. Turn on your Computer and Peripheral Devices.
- 11. Connect an **Ethernet Cable t**o the **Ethernet Port**(s).

Install the Driver

- 1. Navigate to www.startech.com/ST10GSPEXNDP2
- 2. Click the **Drivers & Downloads** tab.
- 3. Under **Driver(s)**, download the **Driver** for your operating system.

For Windows Systems

- a. Extract the contents of the **Driver Package** by **Right Clicking** the **Driver Folder** that was downloaded from the website and select **Extract All**. Follow the on-screen instructions to finish the **Extraction**.
- b. Follow the instructions on the accompanying **ST10GSPEXNDP2_Windows_DIG.pdf** file for further **Installation Instructions.**

For Linux Systems

a. Extract the contents of the Driver Package.

b. Follow the instructions on the accompanying **README.txt** file.

Verify Driver Installation (Windows)

- Navigate to the **Device Manager.**
- Under Network Adapters, right-click Marvell AQtion 10Gbit Network Adapter and click the Properties option.
- 3. Confirm that the Driver is installed and working as expected.

Verify Driver Installation (Linux)

- 1. Run **Ismod** | **grep -i atlantic** from the command line.
- 2. Verify that the **Driver** is present in the command line.

Regulatory Compliance

FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.
 Changes or modifications not expressly approved by <u>StarTech.com</u> could void the user's authority to operate the equipment.

Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

Read the entire manual and ensure the instructions are fully understood before assembling and/or using this

StarTech.com Ltd.

45 Artisans Crescent

London, Ontario N5V 5E9

Canada

StarTech.com LLP

4490 South Hamilton

Road

Groveport, Ohio

43125

U.S.A.

StarTech.com Ltd.

Unit B, Pinnacle 15

Gowerton Road

Brackmills,

Northampton

NN4 7BW

United Kingdom

To view manuals, FAQs, videos, drivers, downloads, technical drawings, and more,

visit www.startech.com/support.



Hard-to-find made easy®

Documents / Resources



StarTech com ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter C ard [pdf] User Guide

ST10GSPEXNDP2 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card, ST10GSPEX NDP2, 2-Port 10GBase-T NBase-T Ethernet Network Adapter Card, NBase-T Ethernet Network Adapter Card, Network Adapter Card, Adapter Card, Card

References

- StarTech.com | IT Pro's Trusted Source for Connectivity Accessories
- 2-Port 10Gbps PCle Network Adapter Card Network Adapter Cards | StarTech.com
- StarTech.com Support
- StarTech.com Warranty Policy

Manuals+,