



StarTech ADJSHELFHD2 1U Adjustable Depth Rack Mount Shelf User Guide

[Home](#) » [StarTech](#) » StarTech ADJSHELFHD2 1U Adjustable Depth Rack Mount Shelf User Guide 

StarTech ADJSHELFHD2 1U Adjustable Depth Rack Mount Shelf User Guide




Contents

- [1 Product Diagram](#)
- [2 Package Contents](#)
- [3 Requirements](#)
- [4 Installation](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Product Diagram

ADJSHELFHD2



Component		Function
1	Shelf Surface	<ul style="list-style-type: none"> Mount the server rack equipment
2	Front Mounting Brackets	<ul style="list-style-type: none"> Fasten Shelf to the Front Posts of the rack or cabinet Holes on the sides of the Mounting Brackets allow for Depth Adjustment. M6x12 mm Screws (x 4) secure the Mounting Brackets to the desired depth Allows for up to 5.7 in (146.9 mm) depth adjustment
2	Rear Mounting Brackets	<ul style="list-style-type: none"> Fasten Shelf to the Rear Posts of the rack or cabinet Holes on the sides of the Mounting Brackets allow for Depth Adjustment. M6x12 mm Screws (x 4) secure the Mounting Brackets to the desired depth Allows for up to 13 in (332.1 mm) depth adjustment

Package Contents

- 1U Shelf Body x 1

- Front Mounting Brackets x 2
- Rear Mounting Brackets x 2
- M6x12 mm Screws x 8
- M6 Cage Nuts x 8
- M6 Plastic Washers x 8
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit: www.StarTech.com/ADJSHELFHD2

- For square cage holes, M6 cage nuts are included. For M6 threaded holes, no cage nuts are needed. Refer to the manufacturer of the rack to determine the mounting hole type
- Phillips head screwdriver
- Cage nut tool (Optional)

Warnings

Read the entire Quick-Start Guide and ensure the instructions are fully understood before assembling and using this product.

Before adding equipment to this product, ensure this product has been properly mounted.

Never operate this product if parts are missing or damaged.

Ensure the weight of the equipment does not exceed the weight capacity of this product. If the weight capacity is exceeded, personal injury or damage to the equipment is possible. This product can support the following weight: up to 264 lb (120 kg). The maximum supported weight is only possible when all four mounting brackets are properly mounted to all posts on a four post rack.

Arrange your equipment in the rack in descending order of weight. The lightest equipment is installed at the top of the rack, and the heaviest is on the bottom.

Installation

1. Locate a suitable location in the rack or cabinet to mount the Shelf. The Shelf requires 1U of Space.
To mount the shelf leveled, ensure the mounting brackets are mounted on the same U height number. To determine this, most four posts racks or cabinets have labeled front and rear posts.
2. Determine the Depth of the Mounting Posts on the rack. The Adjustable Mounting Depth of the Shelf is from 19.5 in (495 mm) to 38.3in (974 mm).
3. Use a Phillips Head Screwdriver to Loosen the Screws of the Front and Rear Mounting Brackets so they can slide freely. Each Mounting Bracket uses Two Screws.
4. (Optional) Remove all the Screws (x 8) of the Front and Rear Mounting Brackets if the adjustment requires different Depth Adjustment Holes on the sides of the Shelf.
5. Adjust the Front and Rear Mounting Brackets to achieve the same Mounting Depth as the Mounting Posts of the rack. Next, secure the Screws (x 8) of the Front and Rear Mounting

Brackets with a Phillips Head Screwdriver.

For cabinets with door(s), the front and rear of the shelf should not protrude past the rack posts to allow the door(s) to close.

6. (Optional) Install the M6 Cage Nuts (x 8) into the appropriate Cage Nut Holes (x 8) on the chosen U Height Number on the Mounting Posts of the rack.

Use a cage nut tool if available or your preferred installation method to install the M6 Cage Nuts.

7. Place the M6 Plastic Washers (x 8) onto the M6x12 mm Screws (x 8).
8. Place the Shelf into the rack in the chosen U Height Number. Align the Mounting Holes of the Front Mounting Posts of the rack with the Front Mounting Brackets. Keep supporting the weight of the Shelf.
9. Use a Phillips Head Screwdriver to install the M6 Screws and fasten the Front Mounting Brackets to the Front Mounting Posts of the rack. Ensure the M6x12 mm Screws are properly tightened.
10. Repeat Step 8 for the Rear Mounting Brackets.
11. (Optional) Make minor depth adjustments to the Front and Rear Mounting Brackets as needed.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders. PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.

Warranty Information

This product is backed by a lifetime warranty. For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Safety Measures

- Read the entire manual and ensure the instructions are fully understood before assembling and/or using this product.

StarTech.com Ltd.

45 Artisans Crescent
London, Ontario
N5V 5E9
Canada

StarTech.com LLP

4490 South Hamilton
Road
Groveport, Ohio


43125
U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Road
Brackmills,
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands



Documents / Resources

	StarTech ADJSHELFHD2 1U Adjustable Depth Rack Mount Shelf [pdf] User Guide ADJSHELFHD2 1U Adjustable Depth Rack Mount Shelf, ADJSHELFHD2, 1U Adjustable Depth Rack Mount Shelf, Adjustable Depth Rack Mount Shelf, Depth Rack Mount Shelf, Rack Mount Shelf, Mount Shelf
--	---