



StarTech P4DD46A2-KVM-SWITCH KVM Dual Monitor KVM Switch Instructions

[Home](#) » [StarTech](#) » StarTech P4DD46A2-KVM-SWITCH KVM Dual Monitor KVM Switch Instructions 

StarTech.com

Hard-to-find made easy®

**P4DD46A2-KVM-SWITCH KVM Dual Monitor KVM
Switch Instructions**

Product IDs

P2DD46A2-KVM-SWITCH
P4DD46A2-KVM-SWITCH

Contents

- [1 Product Information](#)
- [2 Hotkey Commands](#)
- [3 HK_LCode](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Product Information

For the latest software, manuals, product information, technical specifications, and declarations of conformance, please visit:

www.StarTech.com/P2DD46A2-KVM-SWITCH
www.StarTech.com/P4DD46A2-KVM-SWITCH

Hotkey Commands

Hotkey commands are keystroke sequences that initiate computer/device functions and can be used to initiate KVM Switch functions. A hotkey command sequence must be initiated by the HK_LCode (HotKey Leading Code), followed by 1-2 additional keystrokes. Successful hotkey command inputs result in a high-pitch beep. Unsuccessful hotkey command inputs result in a low-pitched beep.

Notes:

- All keystroke combinations must be entered in rapid succession.
- Press and release the indicated keys, unless otherwise specified.

HK_LCode

Option 1.1

- Scr Lck + Scr Lck

Option 1.2

To change the HK_LCode:


- HK_LCode + H + Esc, Caps, or F12
- Alternatively, press and hold the front Host Selection Button for PC2, until 2 beeps are emitted, then press the desired leading hotkey of Scr Lck, ESC, Caps, or F12

Hotkey Command	Function
HK_LCode + 1 ~ 2 or HK_LCode + F1 ~ F2	<ul style="list-style-type: none"> • Select PC 1 or PC 2.
HK_LCode + W	<ul style="list-style-type: none"> • Disable the binding between PC (USB/Video) and Audio when switching between PC 1 or PC 2. • Allows switching of PC Ports USB and Video functions, while Audio does not switch
HK_LCode + Q	<ul style="list-style-type: none"> • Enable the binding of PC (USB/Video) and Audio switching. • Audio will switch with the PC Ports USB and Video functions. • Enabled by default.
HK_LCode + F5 ~ F6	<ul style="list-style-type: none"> • Audio Unbound: Selects only the audio and mic source between PC 1 or PC 2, does not switch USB and Video • Audio Bound: Select PC 1 or PC 2 and their respective USB/Video/Audio Ports
HK_LCode + Up Arrow Key or HK_LCode + Down Arrow Key	<ul style="list-style-type: none"> • Select the next/previous PC Port. • If Audio is unbound, the audio will not switch
HK_LCode + B	<ul style="list-style-type: none"> • Disable the Beep that indicates HotKey Command Inputs.
HK_LCode + S	<ul style="list-style-type: none"> • Enable Autoscan. • Press any key to stop the Autoscan function.
HK_LCode + H + "x"	<ul style="list-style-type: none"> • Define the Autoscan time delay. • "x" = 1 – 10sec, 2 – 20sec, 3 – 30sec, 4 – 40sec, 5 – 50sec, 6 – 60sec, 7 – 70sec, 8 – 80sec, 9 – 90sec, 0 – 100sec

To view manuals, FAQs, videos, drivers, downloads, technical drawings, and more, visit www.startech.com/support.

Hotkey Command Revision: May 11, 2023

Documents / Resources

	StarTech P4DD46A2-KVM-SWITCH KVM Dual Monitor KVM Switch [pdf] Instructions P2DD46A2-KVM-SWITCH, P4DD46A2-KVM-SWITCH, P4DD46A2-KVM-SWITCH KVM Dual Monitor KVM Switch, P4DD46A2-KVM-SWITCH KVM, Dual Monitor KVM Switch, Monitor KVM Switch, KVM Switch, Switch
---	--

References

- [2-Port Dual-DisplayPort KVM Switch, 4K - KVM Switches | Server Management | StarTech.com](#)
- [StarTech.com Support](#)