



Stauer Automatic Skeleton Watch Instruction Manual

[Home](#) » [Stauer](#) » Stauer Automatic Skeleton Watch Instruction Manual

Stauer®
Afford the Extraordinary.

Automatic Skeleton Watch
INSTRUCTION MANUAL




Contents [[hide](#)]

- [1 FEATURES](#)
- [2 WATCH DISPLAY](#)
- [3 TIME SETTING](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

FEATURES

- Automatic Movement: 20 Jewels
- Exhibition back and open heart front
- Sun/Moon function at 12 o'clock
- Dual time subdial at 9 o'clock
- Water resistant to 3 ATM

WATCH DISPLAY



- A – Dual Time Dial
- B – Sun/Moon Display
- C – Crown
- D – Hour Hand
- E – Minute Hand
- F – Open Heart Display

TIME SETTING

TO SET THE TIME

Locate the crown on your Stauer watch (part C) and please note the two crown positions (0-1). Before the watch is worn for the first time, wind the crown, by hand, 10-15 cycles by rolling the crown clockwise (away from you) while in the "0" (one) position.

TO SET THE TIME

1. Pull the crown (part C) out to position "1" and adjust the dual-time dial (part A). Turn the crown counter-clockwise until the small hand reaches 12.
2. Continue to turn the crown clockwise to set the time difference between local (main dial) and dual time (Part A).
3. To adjust the local time (main dial), turn the crown clockwise and set the desired local time.

NOTE: The Sun/Moon display (Part B) will synchronize with the local time.

4. Once the time is set, push the crown back into "0" position.

Visit us at www.stauer.com

to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com

Documents / Resources



[Stauer Automatic Skeleton Watch](#) [pdf] Instruction Manual
Automatic Skeleton Watch

References

- [S Stauer Jewelry - Afford the Extraordinary](#)