

STEALTH CAM Digital Scouting Camera DS4KU Firmware Update Instruction Manual

 $\underline{\textbf{Home}} \text{ * } \underline{\textbf{STEALTH CAM}} \text{ * } \underline{\textbf{STEALTH CAM Digital Scouting Camera DS4KU Firmware Update Instruction Manual}$

Contents

- 1 STEALTH CAM Digital Scouting Camera DS4KU Firmware Update
- 2 Documents / Resources
- **3 Related Posts**



STEALTH CAM Digital Scouting Camera DS4KU Firmware Update



DS4KU Firmware Update Version V01.00.29

Note: It is recommended to perform the software update using new batteries. Loss of battery power during the software update may cause the camera to be non-operational.

- 1. Download the DS4KU-01.00.29.zip file.
- 2. Unzip the file.
- 3. Copy the Software Update File AICAM.BRN to the root directory of an SD Card.
- 4. Place the SD Card into the SD Card slot of the camera.
- 5. Move the switch to the ON position to power up the camera.
- 6. Press MENU to enter the menu selection.
- 7. Press the Up Arrow twice to select the SW UPGRADE menu item.
- 8. Press the ENTER button then the UP button to change the selection to YES.
- 9. Press the ENTER button to start the upgrade process.
- 10. The upgrade process takes approximately 2 minutes to complete. The screen will display software upgrade text during the update (see Figure 1)



(Figure 1. Firmware Update Text)

Warning: Do not turn camera off or eject battery tray during the software upgrade process. Loss of power to the camera may cause damage.

11. Once the update is complete, the LCD screen will briefly turn off and the camera should automatically reboot to the main screen and be ready to use.

Documents / Resources



<u>STEALTH CAM Digital Scouting Camera DS4KU Firmware Update</u> [pdf] Instruction Manual STEALTH CAM, Digital, Scouting, Camera, DS4KU, Firmware Update

Manuals+, home privacy