



# STEALTH PS4 SETUP 520 Turtle Beach User Guide

[Home](#) » [STEALTH](#) » STEALTH PS4 SETUP 520 Turtle Beach User Guide 

## Contents

- [1 STEALTH PS4 SETUP 520 Turtle Beach](#)
- [2 PS4™ SETUP](#)
- [3 NINTENDO SWITCH™ SETUP](#)
- [4 PC / MOBILE & TABLET](#)
- [5 Legal information](#)
- [6 Warranty](#)
- [7 CE](#)
- [8 HAVING TROUBLE SETTING UP? WE CAN HELP!](#)
- [9 PACKAGE CONTENTS](#)
- [10 CONTROLS](#)
- [11 XBOX SETUP](#)
- [12 XBOX SETUP HEADSET CHAT MIXER](#)
- [13 XBOX SETUP SURROUND SOUND](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)

**STEALTH®**

**STEALTH PS4 SETUP 520 Turtle Beach**



## PS4™ SETUP




In order to hear the in-game audio through the headset, you must make sure that your ps4™ system is set-up as follows:

- Settings > Devices > Audio Devices > Output to headphones > All audio
- ADJUST THE HEADSET AUDIO LEVELS the volume level of the headset and microphone can be adjusted within the ps4™ system menu as follows:
- HEADSET VOLUME: Settings > Devices > Audio devices > Volume control (headphones)


- **MICROPHONE LEVEL:** Settings > Devices > Audio devices > Adjust microphone level  
(Adjust the microphone level until the indicator shows 'good')

## NINTENDO SWITCH™ SETUP



Insert the headset's 3.5mm jack plug into your Nintendo Switch™ Console. The Headset should work upon connection. Chat available for games that support chat.

## PC / MOBILE & TABLET



- Most new pc's have a single 3.5mm jack connection. Simply plug the 3.5mm jack from the headset directly into the port on your PC. The same applies when connecting to a mobile or tablet.
- If your PC uses separate Green/Pink connectors you will need a PC Splitter Cable (Sold Separately)

## Legal information

Please keep this instruction manual for future reference. If you require any help or assistance please contact the Helpline or VISIT [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)

## Warranty

This product is guaranteed for a period of one year from the date of purchase. During this period if there is a defect due to faulty materials, or workmanship the retailer from whom you purchased it will replace it with the same or a similar model on production of your purchase receipt or proof of purchase. This guarantee does not cover defects arising from accidental damage, misuse or wear and tear, and is available only to the original purchaser of the product. This does not affect your statutory rights.

To prevent possible hearing damage, do not listen at high volume levels for long periods.

## Precautions

- Ensure that the volume control is set to the minimum level before connecting the headset to your system
- Before wearing the headset, set the volume control to its minimum level then slowly increase until you reach your desired volume level
- Listening to your headset at its maximum level may cause damage to both the headset and your ears
- Long term exposure to loud music or other sounds in a headset may cause hearing damage. It is best to avoid very high volume levels when using a headset, especially for extended periods

## Important Safeguards & Precautions

- Never expose to direct sunlight or wet weather conditions
- Do not expose the unit to splashing, dripping, rain or moisture. Do not immerse in liquid
- Do not expose to dust, high humidity, high temperatures or mechanical shock
- Avoid any unnecessary strain of the cable
- Do not carry the headset by its cable
- Do not use if the equipment is damaged
- Do not disassemble; there are no serviceable parts inside
- For external cleaning, use a soft, clean, damp cloth only. Use of detergents may damage the cabinet finish and leak inside

## Recycling

- Where you see this symbol on any of our electrical products, batteries or packaging, it indicates that the relevant electrical product or battery should not be disposed of as general household waste in the EU or Turkey. To ensure the correct waste treatment of the product and battery, please dispose of them in accordance with any applicable local laws or requirements for disposal of electrical equipment/batteries. In so doing, you will help to conserve natural resources and improve standards of environmental protection in treatment and disposal of electrical waste.
- The recycling and processing of Waste Electrical and Electronic Equipment will make a significant contribution towards helping protect the environment by reducing landfill waste.
- Not recommended for children under 6 years of age.

Marking of this symbol indicates this product has been tested and is compliant with the EMC Directive of the European Union 2014/30/EU.

Not recommended for children under 6 years of age. Please retain this packaging for future reference. Due to the company's policy of constant improvement and technical refinement, the company reserve the right to alter the specification. This product is not sponsored, endorsed or approved by Microsoft. XBOX ONE™ is a registered trademarks of Microsoft Co. Ltd. This product is not sponsored, endorsed or approved by Sony Interactive Entertainment. PS4™ is a registered trademarks of Sony Interactive Entertainment. This product is not sponsored, endorsed or approved by Nintendo. Nintendo Switch™ is a registered trademark of Nintendo Co. Ltd. Manufactured by ABP Technology Ltd. Bolton, BL2 1BX. MADE IN CHINA.

## HAVING TROUBLE SETTING UP? WE CAN HELP!

### TECHNICAL SUPPORT QUESTIONS / SET UP / NOT WORKING?

- **ONLINE:** [STEALTHGAMING.NET/SUPPORT](https://stealthgaming.net/support)
- **EMAIL:** [HELP@ABPTECH.CO.UK](mailto:HELP@ABPTECH.CO.UK)
- **LIVE CHAT:** Speak to our Support Team by clicking the 'Chat With Us' box over at stealthgaming.net
- MONDAY-THURSDAY 9AM to 5PM
- FRIDAY 9AM to 4PM

### PACKAGE CONTENTS




PANTHER GAMING HEADSET

### CONTROLS


#### 1. MICROPHONE BUTTON

- **PRESS IN** – MICROPHONE IS ACTIVE/ON
- **PRESS OUT** – MICROPHONE IS MUTED



## 2. MASTER VOLUME – GAME & CHAT

**NOTE:** PLEASE MAKE SURE THE VOLUME IS TURNED UP AND THE MIC IS SWITCHED ON




## XBOX SETUP




**NOTE:** IF YOU ARE USING AN ORIGINAL XBOX ONE™ CONTROLLER YOU WILL REQUIRE THE \*XBOX ONE STEREO HEADSET ADAPTER (SOLD SEPARATELY)

## XBOX SETUP HEADSET CHAT MIXER

1. Press the XBOX button on your controller
2. Go to the System tab 
3. Select Audio
4. Ensure the headset Mic is turned on
5. Set the Headset Volume to maximum
6. Set the Headset Chat Mixer to the middle
7. Set the Mic Monitoring to your desired level

## XBOX SETUP SURROUND SOUND

1. Press the XBOX button on your controller
2. Go to the System tab 
3. Select Settings > Display & Sound > Audio Output
4. Select headset to Windows Sonic for Headphones

## Documents / Resources



**[STEALTH PS4 SETUP 520 Turtle Beach](#)** [pdf] User Guide  
PS4 SETUP, 520 Turtle Beach, PS4 SETUP 520 Turtle Beach

## References

- [Stealth Gaming Headset Online](#) | [Stealth Gaming Accessories](#) | [Stealthgaming.net](#)

Manuals+.