

Contents [[hide](#)]

- [1 Stinger iE268 Navigation Multimedia Receiver](#)
- [2 Specifications](#)
- [3 Main Menu](#)
- [4 Android Auto](#)
- [5 Connect the wireless carplay](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



Stinger iE268 Navigation Multimedia Receiver



Specifications

- **Model NO.:** iE268
- **Model Name:** NAVIGATION MULTIMEDIA RECEIVER

Main Menu



1. All Menus

- **Radio:** Converts to the last played radio mode.
- **SiriusXM:** Listen to the channel


- **Audio Settings:** Sound settings
- **Android Auto:** Run the Android Auto function.
- **Apple CarPlay:** Runs the Apple CarPlay function.
- **Settings:** Moves to the settings menu.

2. All Menus

- **BT Phone:** Answer and make a call
- **Bluetooth:** Connect the mobile phone to play mobile audio
- **USB:** Converts to the last played USB mode.
- **Camera:** Show the camera picture
- **Display Off:** The device enters the screen off state



Radio




- **FM** Click to switch FM mode.
- **AM** Click to switch AM mode.
- **Distant/Loc** : Search the range of channels
- **Auto** : Channel search mode
- **Press**  Manual input channel

Siriusxm




- SXM Click to switch FM
- Press  Manual input channel
- Press  SiriusXM Settings

Audio Settings




- **Settings** You can adjust the sound position by clicking the up/down/ left / right arrow.



- **Equalizer** You: You can set the equalizer by yourself and save it




- **Crossover** You can adjust Slope Frequency Level of these parameters



- **Factory EQ** You can choose a Factory EQ model.

Android Auto





Apple CarPlay

Note ·The Bluetooth source of the machine is not available when the CarPlay is connected.




Connect the wireless carplay


1. press [settings-device-device list] to the wireless CarPlay connection interface
2. Click [add a device] to search for available wireless CarPlay devices. Press the cancel button to stop the search.
3. Click the button  to connect to the paired device, and click the  button to delete the paired device.

Settings

- Press the [Settings] icon on the All Menus interface to enter the setup menu interface.




- Press[Clock]: You can set the device time
- Press[Microphone]: You can set the Microphone
- Press[System Beep Volume]: You can set the beep switch
- Press[Language]: You can set the Language



- Press[Auto Brightness]: You can set auto brightness
- Press[Display Brightness]: You can set the brightness of the screen
- Press[Face Button Color]: You can set the color of the panel light


- Press[Face Button Brightness]: You can set the color of the light on the engine panel
- Press[Background]: You can set the background of the machine



BT Phone


Phone Dial

- Click on the display keyboard to make a call




Favourites

- Click to display favorites
- If you do not have any favorites, you can click on Add Favourites from contacts to add favorite contacts



Call History

- Show cell phone records




Contacts

- Tap to show your phone contacts



Settings

- Click to display the device connected to the machine



Bluetooth


When Bluetooth is connected, click to play BT music.




- Press[Previous button]: You can switch to the previous one
- Press the [Next button]: You can switch to the next song

USB

When the USB disk is inserted, the USB music icon is highlighted. Click USBmusic to enter the USB music interface.



Pause

- You can pause the playing file
- Press [] on the screen.

Play

- Press [] on the screen to play it again.

Previous button

- When it is pressed for a short time.
- Press the previous button to switch to the last video (playing progress does not exceed 5 seconds).
- Press the previous button, the currently playing video will restart (Play progress exceeds 5 seconds).
- When it is pressed and held ·Rewind the currently playing video

Next button

- When it is pressed for a short time. ·Press a button to cut to the next video
- When it is pressed and held. ·Fast forward the currently playing video

Repeat

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

File Button


- You can choose to play music, video, or pictures

Search Button

- You can search for the USB file you are looking for.

Cameras

Press [Camera] interface shows the camera picture..



FCC Compliance Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference,
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The distance between the user and the products should be no less than 20cm. This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FAQs


Q: How do I connect my mobile phone via Bluetooth?

A: Go to the Bluetooth menu, click on the device list, and select your phone to connect.

Q: Can I customize the panel light color?

A: Yes, you can set the color of the panel light in the Face Button Color settings.

Documents / Resources

	Stinger iE268 Navigation Multimedia Receiver [pdf] User Manual XBD-IE268, XBDIE268, iE268 Navigation Multimedia Receiver, iE268, Navigation Multimedia Receiver, Multimedia Receiver, Receiver
---	---

References

- [User Manual](#)

Stinger

iE268, iE268 Navigation Multimedia Receiver, Multimedia Receiver, Navigation Multimedia Receiver, Receiver, Stinger, XBD-IE268, XBDIE268

—Previous Post

[Stinger JKUAMPBRKTD Amp Bracket Instruction Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.