

STREAMLIGHT PROTAC 2.0 Headlamp Instruction Manual

Home » StreamLight » STREAMLIGHT PROTAC 2.0 Headlamp Instruction Manual





available at **BrightGuy.com PROTAC® 2.0 HEADLAMP Operating Instruction**

Contents

- 1 PROTAC 2.0 Headlamp
- 2 CHARGING
- **3 GENERAL OPERATION**
- **4 PRODUCT USE**
- **5 STREAMLIGHT LIMITED LIFETIME WARRANTY:**
- 6 Documents / Resources
 - **6.1 References**

PROTAC 2.0 Headlamp

IMPORTANT: FULLY CHARGE BATTERY BEFORE FIRST USE.

Thank you for selecting the ProTac® 2.0 Headlamp, a truly remarkable light. As with any professional tool, reasonable care and maintenance of this product will provide years of dependable service. Please read this manual before using the ProTac® 2.0 Headlamp. It contains important safety and operating instructions and

SAVE THESE INSTRUCTIONS. This guide contains important safety and operating instructions for your ProTac® 2.0 Headlamp.



Fire and burn hazard. The ProTac® 2.0 Headlamp provides a powerful beam. When operated for more than a few

seconds, it will get hot. Never leave your ProTac® 2.0 Headlamp with its face against any surface, including skin, while in operation. Transport or store the ProTac® 2.0 Headlamp in a way that minimizes the chance it can accidentally be turned on. The resultant heat build-up can cause a fire, burns or damage to the flashlight.

LED SAFETY

CAUTION LED RADIATION (RG-2). DO NOT STARE INTO BEAM. MAY BE HARMFUL TO EYES. PER IEC 62471 Ed 1.0:2006-07.

BATTERY SAFETY

CAUTION EXPLOSION RISK, BURN, AND FIRE HAZARD. DO NOT DISASSEMBLE, CRUSH, SHORT CIRCUIT, HEAT ABOVE 140°F (60°C), OR DISCARD IN FIRE.

USE ONLY WITH THE SPECIFIED STREAMLIGHT PRODUCTS. KEEP AWAY FROM CHILDREN. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

CHARGING

NOTICE

Charge battery before first use.

The ProTac® 2.0 Headlamp system ships with a rechargeable SL-B50® Li-lon battery. The SL-B50® battery is recyclable. At the end of its useful life, under various country and state laws, it may be illegal to dispose of this battery in the municipal solid waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal (in USA: RBRC).

The SL-B50® battery can be charged outside the light or while installed. The battery itself contains charge circuitry and indicators for charging. The battery may be left plugged into a USB-C cable continuously, there is no danger of overcharge.

To charge inside the light, first turn off the light. Slide down the access ring at the base of the head to uncover the USB-C port. Plug the USB-C connector into the USB-C port and plug the other end of the cord into a power source. LED charge indicators are located on the battery adjacent to the USB-C plug.

Battery LED Charge Indicators

- · Charging...Red LED is on.
- Charged...Green LED is on.

Charge time is approximately 6 hours when using Stream light AC adapters.

CHARGE CORD SAFETY

- · Don't abuse the cord.
- Replace damaged cords or plugs immediately.
- Remove light from charge before attempting any routine cleaning or maintenance.
- Do not try to repair the unit or cord yourself. Take it to a qualified service facility or return it to the factory.

GENERAL OPERATION

Before first use, install and charge the battery. Remove the tailcap and insert the battery.

Note that the tailcup thread will not engage unless the battery is properly orientated. Rotate the battery until it drops in place and reinstall the tailcap.

The ProTac® 2.0 Headlamp features a programmable switch with momentary operation (light press or tap) and constant on operation (press until click).

- High: Tap and hold; click to lock on; click again for off.
- Medium: Fast double-tap (within 0.4 seconds) and hold; click to lock on; click again for off.
- Low: Fast triple-tap (within 0.4 seconds per tap) and hold; click to lock on; click again for off.

Accessing Other Programs

The Protect® 2.0 Headlamp features a TEN-TAP® programmable switch allowing the user to select one of three different programs. To change to the next program, starting from the "Off" position, tap the switch rapidly 9 times (within 0.4 seconds per tap) and hold it down the 10th time. Continue holding the switch until the light turns off (approximately 1 second), then release the switch.

Available programs are High-Medium-Low (Factory Default), High only or Low-Medium-High.

PRODUCT USE

Stream light flashlights are intended for use as high intensity, heavy duty, and portable light sources. Use of Streamlight flashlights for any purpose other than as light sources is specifically discouraged by the manufacturer. Stream light specifically disclaims liability for other than recommended use.

NOTICE

Be sure to use only genuine Stream light replacement parts. To assure product safety always use Streamlight approved replacement parts, substitution may invalidate the product approval. Do not try to repair the unit yourself. Send to a qualified service facility or return it to the factory.

STREAMLIGHT LIMITED LIFETIME WARRANTY:

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW. You may have other specific legal rights which vary by jurisdiction.

Go to <u>www.streamlight.com/support</u> for a complete copy of the warranty. To register your product, go to <u>www.streamlight.com</u> (Online Product Registration). Retain your receipt or any proof of purchase.

SERVICE OPTIONS

The Protac® 2.0 Headlamp contains few user-serviceable parts.

For service options, go to <u>www.streamlight.com/support/service</u> and complete the Online Service Request for factory service or to find the location of an authorized Streamlight repair center near you.

Or contact:


Customer Service STREAMLIGHT, INC. 30 Eagleville Road Suite 100

Eagleville, PA U.S.A. 19403-3996

Phone: (800) 523-7488 Toll-Free / +1 (610) 631-0600

Fax: (800) 220-7007 / +1 (610) 631-0712

Documents / Resources



References

- <u>FarightGuy Flashlights, Headlamps, Work Lights, Police Flashlights</u>
- Streamlight Tactical & Safety Rated Flashlights & Headlamps
- Streamlight Tactical & Safety Rated Flashlights & Headlamps
- Support
- Service Options

Manuals+,