



30426-30427 ANC Earbuds User Manual

[Home](#) » [Strong Current](#) » 30426-30427 ANC Earbuds User Manual 

USER MANUAL



ANC Earbuds
Model: 30427 ANC earbuds (White)

Contents

1

Button Definition

2

Restore the factory settings

3

FCC Statement

4

Related Posts

Button Definition

“L” “R” Earbud:

- Touch and hold for 2-3seconds: Transparency mode /Active noise cancellation
- Touch and hold for 2-3 seconds :hang up / reject phone call
- Press to Play/Pause/Answer
- Double -press to skip forward
- Triple-press to skip back

Restore the factory settings

Put the earphones into the charging case and open the case cover , first press the button of the case twice ,and then press the button of the case for a long time until the case's show white LED blink , the earphones will be factory reset.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

[30426-30427-ANC-Earbuds-Manual-Optimized](#)

Optimized PDF

[30426-30427-ANC-Earbuds-Manual-Original](#)

Download

Questions about your Manual? Post in the comments!

