




STRONG 4G+ROUTER1200 Wi-Fi LTE Router Installation Guide

[Home](#) » [STRONG](#) » STRONG 4G+ROUTER1200 Wi-Fi LTE Router Installation Guide 



4G+4G+ LTE ROUTER
4G+ROUTER1200
Mbps
1200
Mbit/s




Installation Instructions

Contents


- [1 4G+ROUTER1200 Wi-Fi LTE Router](#)
- [2 SERVICE CENTER](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

4G+ROUTER1200 Wi-Fi LTE Router



If required, please enter the PIN code of your SIM card going through steps 6 and 7


5a



5b



6



SERVICE CENTER


 supportuk@strong.tv



0800 464 7919




www.strong.tv



Supplied by STRONG AUSTRIA
Represented by STRONG Ges.m.b.H
Teinfaltstraße 8/4.Stock
A-1010 Vienna, Austria
Email : support_at@strong.tv

Documents / Resources



[STRONG 4G+ROUTER1200 Wi-Fi LTE Router](#) [pdf] Installation Guide
4G ROUTER1200, 4G ROUTER1200 Wi-Fi LTE Router, Wi-Fi LTE Router, LTE Router, Router

References

- [Home | Strong-eu.com](#)