



# STYLE SELECTIONS CL22-11ST 9 Cube Storage Organizer Instruction Manual

[Home](#) » [Style SELECTIONS](#) » STYLE SELECTIONS CL22-11ST 9 Cube Storage Organizer Instruction Manual 



## Contents

- 1 CL22-11ST 9 Cube Storage Organizer
- 2 CARE AND MAINTENANCE
- 3 WARRANTY
- 4 PREPARATION
- 5 SAFETY INFORMATION
- 6 OPERATING INSTRUCTIONS
- 7 PACKAGE CONTENTS
- 8 HARDWARE CONTENTS
- 9 ASSEMBLY OVERVIEW
- 10 Documents / Resources
  - 10.1 References

## CL22-11ST 9 Cube Storage Organizer

### ITEM

#5120837, 5120838,

5120839, 5130296, 5130297

STYLE SELECTIONS and logo design are trademarks or registered trademarks of LF, LLC.

All rights reserved.

### MODEL

#CL22-11ST9-BLK

CL22-11ST9-RYE

CL22-11ST9-GR4

CL22-11ST9-W.

CL22-11ST9-ES

Thank you for purchasing this STYLE SELECTIONS product. We've created these easy-to-follow instructions to ensure you spend your time enjoying the product instead of putting it together. But, if you need more information than what is provided here, please visit [Lowes.com](https://www.lowes.com), search the item number and refer to the Guides & Documents tab on the product's page.

[877-888-8225](tel:877-888-8225), 8 a.m. – 8 p.m.,

EST, Monday – Sunday. You could also contact us at [partsplus@lowes.com](mailto:partsplus@lowes.com).

If the item is no longer for sale, or if you have any questions or problems, please call our customer service department at

## CARE AND MAINTENANCE

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Using any kind of solvent on your furniture may damage the surface.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Make sure all bolts/screws are tightly fastened before the unit is used, check bolts/screws periodically and tighten them if necessary
- In the event that your furniture is stained or otherwise damaged during use, we recommend that you call a professional to repair your furniture.

## WARRANTY

- This limited warranty covers the original purchase of this product used for normal commercial, personal, or

household use. Style Selections warrants its products will be free from defects in materials and workmanship (normal wear and tear expected), for a period of one (1) year from the date of purchase, except as provided below. As the exclusive remedy under this warranty, Style Selections will repair or replace any defective furniture component.

- This warranty does not apply to damage caused by fire, accident, negligence, misuse, use other than as stated in product instructions, improper cleaning or other circumstances not directly attributable to defects in materials and workmanship.
- Materials are warranted for one year from date of purchase. Proof of purchase is required in the form of a receipt (copy or original) to validate the warranty.

THIS WARRANTY APPLIES ONLY TO THE U.S. AND CANADA.


## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 15 minutes

### TOOLS REQUIRED



## FEELING CONFIDENT? START YOUR NEXT PROJECT

- Visit [www.lowes.com](http://www.lowes.com) for more information.



## SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

### WARNING


- Serious or fatal crushing injuries can occur from furniture tip-over.
- Use of anti-tip device may only reduce, but not eliminate, the risk of tip-over, so never allow children to climb or hang on drawers, doors or shelves. /El uso del dispositivo contra volcaduras solo puede reducir, pero no eliminar, el riesgo de vuelco.
- Do not alter this product in any manner.
- Place heaviest items in the lowest level.
- Do not set TV's or other heavy objects on top of this product, unless specifically designed to accommodate.
- When storing articles, equally distribute loads, do not position all contents of a shelf in the front portion of the

shelf, always balance the loads to avoid tipping.


- Keep the product on level surfaces. The product may become unstable and it may tip over if stored or moved on an uneven surface, which may cause personal injury or product damage.

## OPERATING INSTRUCTIONS

- This unit has been designed to support the maximum loads shown.
- Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.




## PACKAGE CONTENTS











## HARDWARE CONTENTS

**Note:** Hardware shown actual size.



## ASSEMBLY OVERVIEW



**Style**<sup>®</sup>  
SELECTIONS



[STYLE SELECTIONS CL22-11ST 9 Cube Storage Organizer](#) [pdf] Instruction Manual  
CL22-11ST, CL22-11ST, CL22-11ST, CL22-11ST, CL22-11ST9-ES, CL22-11ST 9 Cube  
Storage Organizer, CL22-11ST, 9 Cube Storage Organizer, Storage Organizer, Organizer

## References

- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.