



# Stylecraft L333329CUECOM Bentley Table Lamp Light Instruction Manual

[Home](#) » [STYLECRAFT](#) » Stylecraft L333329CUECOM Bentley Table Lamp Light Instruction Manual 

## Contents


- [1 Stylecraft L333329CUECOM Bentley Table Lamp Light](#)
- [2 IMPORTANT SAFETY INSTRUCTIONS](#)
- [3 FCC WARNING](#)
- [4 Assembly Instructions](#)
- [5 Light bulb replacement](#)
- [6 CARE & MAINTENANCE](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



**Stylecraft L333329CUECOM Bentley Table Lamp Light**



**Set of 2 Table Lamps**  
M# L333329CUECOM



#### **ASSEMBLY AND USE INSTRUCTIONS**

- **IMPORTANT:** Retain for future reference. Read Carefully.
- Have questions, concerns, feedback? Stylecraft is happy to help! Contact our Customer Service for assistance before you return the item.
- **Customer Service:** Mon. – Fri., 9:30 AM – 3:30 PM, Central Time (English only), Countries available:

- US +1-855-766-1880
- [customerservice@stylecraft-us.com](mailto:customerservice@stylecraft-us.com)

## Manufactured by

- Stylecraft Home Collection Inc.
- 8474 Market Place Drive Suite 104, Southaven, Mississippi 38671, USA

## IMPORTANT SAFETY INSTRUCTIONS



- **CAUTION!** Risk of electric shock
- **Important:** Inspect the wire insulation for any cuts, abrasions or exposed copper that may have resulted from shipping. If there is a defect in the wire, do not continue assembly. Please call our customer service hotline: +1-855-766-1880 MON.-FRI., 9:30 A.M. TO 3:30 P.M. central time, (English only), or email us at [customerservice@stylecraft-us.com](mailto:customerservice@stylecraft-us.com).

For indoor use only! Unplug before assembling and unplug when replacing the lamp bulb.

- Do not exceed the recommended wattage. Refer to the re-lamping label on the light socket for maximum wattage.
- Do not replace a bulb when electrical outlet switch is in the “ON” position.
- Do not immerse your lamp in water; doing so will damage the wire.
- Before you work on any electrical fixture, you must be aware of the hazards involved with electrical circuitry and be familiar with the standard codes and practices for preventing accidents and reducing the risk of fire, electric shock, or personal injury.
- Please make sure that the power outlet box in your home is properly grounded and directly supported by the building structure.
- Keep materials that burn easily away from lit bulbs.

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter plug.

## FCC WARNING

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

## NOTE:


- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

## Assembly Instructions

1. Carefully unpack and place all parts on a smooth surface and line up the parts as illustrated.
2. Screw part B onto lamp base (A) and gently pull cord out of lamp base.
3. Insert harp (C) into saddle of socket section of part B.
4. Screw bulb (included) into lamp holder (B).
5. Place shade (D) onto harp (C), tighten it with finial (E), and adjust the shade.
6. Insert the plug into wall outlet, turn on switch and enjoy your new lamp.



## Light bulb replacement

Use 100 watt or smaller type A bulb (not included) or use maximum 9 watt LED bulb (included).

## CARE & MAINTENANCE

Do not use polishes or cleaners on your lamp. Unplug lamp, clean with a soft, dry cloth. Clean shade with soft dry cloth.

### Distributed by:

- Costco Wholesale Corporation
- P.O. Box 34535
- Seattle, WA 98124-1535
- USA
- 1-800-774-2678
- [www.costco.com](http://www.costco.com)

## MADE IN CHINA

---

## Documents / Resources

	<p><a href="#">Stylecraft L333329CUECOM Bentley Table Lamp Light</a> [pdf] Instruction Manual L333329CUECOM Bentley Table Lamp Light, L333329CUECOM, Bentley Table Lamp Light, Table Lamp Light, Lamp Light, Light</p>
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.