

Styletech
**M400 Silent
Multi Mode
Wireless Mouse**



styletech M400 Silent Multi Mode Wireless Mouse User Manual

[Home](#) » [Styletech](#) » styletech M400 Silent Multi Mode Wireless Mouse User Manual 

Contents

- 1 styletech M400 Silent Multi Mode Wireless Mouse
- 2 Inserting the AA Battery
- 3 Bluetooth Connection
- 4 WARRANTY
- 5 IMPORTANT SAFEGUARDS & PRECAUTIONS
- 6 BATTERY CARE
- 7 FCC STATEMENT
- 8 CONTACT
- 9 Documents / Resources
 - 9.1 References

Styletech

styletech M400 Silent Multi Mode Wireless Mouse



Inserting the AA Battery

The battery will already be installed inside the mouse.

- Simply lift off the front of the mouse cover.
- The mouse cover should lift off easily as it has a magnetic fixing
- Gently pull the paper strip towards you to activate the battery and discard

Connecting the Mouse to Devices

- Connect to any Bluetooth/2.4G supported devices compatible with Windows, Mac, iOS, and Android. Switching easily between operating systems.

24G Connection

- Connecting to 24G you will need to use the dongle (included) stored within the mouse.
- Simply lift off the front of the mouse cover and you will see it situated in the bottom left-hand corner.
- The mouse cover should lift off easily as it has a magnetic fixing.

Power on the mouse

- Insert the USB dongle into any spare USB
- A port on your PC/Laptop
- Select 2.4G (Left) by pressing the button below the LEDs on the base of the mouse.
- It will light solid green to signal the mouse is connected and then go off

Bluetooth Connection

- Power on the mouse Select Bluetooth 1 (Middle LED) by pressing the button above the LEDs on the base of the mouse. It will light solid green
- Instantly, press and hold Bluetooth 1 (Middle LED) for 3-5 seconds to enter pairing mode. The LED light will start to flash rapidly above the button
- In your Bluetooth settings, the mouse name STY-M400 B3 or STY-M400 B5 will appear.
- If using an up-to-date operating system, then select STY-M400 B5 The mouse will connect to your device

Please Note: STY-M400 B3 will only appear if you are using an older operating system.

- To connect to another Bluetooth device, simply follow steps 2-5 above, selecting Bluetooth 2 (Right)

Switching between Devices

- Once you have connected all your required compatible devices to the mouse, you can easily switch between any of them by pressing the button situated on the base of the mouse.
- To wake up the mouse once its entered sleep mode, just double-click and move the mouse.
- A set sensitivity of 1200 dpi is assigned to the mouse.

LEGAL INFORMATION

- Please keep this instruction manual for future reference.
- If you require any help or assistance, please contact the helpline or visit styletech.net.

WARRANTY

- This product is guaranteed for one year from the date of purchase.
- During this period, if there is a defect due to faulty materials or workmanship, the retailer from whom the model on production pours the receipt or promisor purchase.
- This guarantee does not cover defects arising from accidental damage, misuse, or wear and tear and is available only to the original purchaser of the product. This does not affect your statutory rights.

BATTERY WARNING

- Improperly replaced batteries may present a risk of leakage, explosion, and personal injury. There is a risk of fire or explosion if the battery is replaced by an incorrect type.
- Ensure the batteries are installed correctly by following the instructions provided. Miss use of all types of batteries may present a risk of fire or chemical burn. Do not expose batteries to moisture, liquids, or extreme heat. A battery subjected to extremely low air pressure may result in the explosion or leaking of flammable liquid or gas. Do not charge or use the battery if it appears to be leaking or is discolored and deformed. Do not leave your batteries unused for extended periods. Do not short-circuit.
- Your device may contain a built-in rechargeable battery that is not replaceable. Battery life varies with the device and other varying factors. All non-operating batteries must be discarded correctly, according to your local

laws.

- If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep all batteries away from children.

CLASS 1 LASER PRODUCT

INVISIBLE LASER RADIATION This product contains a Class 1 LED. A Class 1 laser is safe under all conditions of normal use. This means the maximum permissible exposure (MPE) cannot be exceeded when viewing a laser with the naked eye or with the aid of typical magnifying optics.

WARNING: Use of controls, adjustments or performance of procedures beyond those specified may result in hazardous radiation exposure. Avoid prolonged direct eye/skin contact with the laser may result in burn injury.

IMPORTANT SAFEGUARDS & PRECAUTIONS

- Never exposed to direct sunlight or wet weather conditions
- Do not expose the product to splashing, dripping, rain or moisture. Do not immerse in liquid
- Do not expose to dust, high humidity, high temperatures or mechanical shock
- Do not use if the equipment is damaged
- Do not disassemble; there are no serviceable parts inside
- For external cleaning, use a soft, clean, damp cloth only.
- Use of detergents may damage the cabinet finish and leak inside
- Do not direct the infrared/laser beam from the mouse to anyone's eye or a reflective object that could injure you
- If the product is trying to operate at out of temperature ranges, power off until the temperature is stabilized
- Long periods of use may result in neck, arm, shoulder, and wrist advice from professionals gular discoid seek healthy

BATTERY CARE

- For full battery core, please see the battery warning section
- If the battery has a charging function it should be under acuit supervision
- Once fully charged disconnect the USB charging cable
- Do not attempt to charge any other battery pack or device using the Us charging cable
- Do not leave on charge for longer than 6 hours
- We do not recommend leaving on charge overnight or while unattended
- Never dispose of batteries in a fire, as this can cause them to
- Do not attempt to remove the product-built battery pack, it is not replaceable
- Power off the device when not in use
- Do not leave unused batteries for extended periods

RECYCLING

Where you see this symbol on any of our electrical products, batteries or packaging, it indicates that the relevant electrical product or battery should not be disposed of as general household waste in the UK, EU or Turkey. To ensure the correct waste treatment of the product and battery, please dispose of them under any applicable local laws or requirements for disposal of electrical equipment/batteries. In so doing, you will help to conserve natural resources and improve standards of environmental protection in the treatment and disposal of electrical waste.



The recycling and processing of Waste Electrical and Electronic Equipment will make a significant contribution towards helping protect the environment by reducing landfill waste.

FCC STATEMENT

FEDERAL COMMUNICATION COMMISSION CLASS 8 INTERFERENCE STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RADIATION EXPOSURE STATEMENT

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class 8 digital device, according to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CANADIAN ICES STATEMENTS

CANADIAN DEPARTMENT OF COMMUNICATIONS RADIO INTERFERENCE REGULATIONS

This digital apparatus does not exceed the Class B limits for radio-noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-002

- All other trademarks are the property of their respective owners.
- Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.
- Not recommended for children under 6 years of age. Please retain this packaging for future reference. Due to the company's policy of constant improvement and technical refinement, the company reserves the right to alter the specification.
- Styletech™ is a registered trademark of ABP Technology Ltd.
- Manufactured By: abp Technology LTD, Bolton, UK, BL2 1BX. EU AR: ABP Technology Europe Ltd. Dublin, ROI, K78 X5W6.

MADE IN CHINA

- The marking of this symbol indicates this product has been tested and is compliant with the EMC Directive of the European Union 2014/30/EU.


- Marking of this symbol indicates this product

CONTACT

HAVING TROUBLE SETTING UP?

- WE CAN HELP!
- EMAIL: help@abptech.co.uk
- How can we help? Our support
- team will answer your questions

Documents / Resources



[styletech M400 Silent Multi Mode Wireless Mouse](#) [pdf] User Manual
STY-M400, 2BKH8-STY-M400, 2BKH8STYM400, M400 Silent Multi Mode Wireless Mouse, M400, Silent Multi Mode Wireless Mouse, Multi Mode Wireless Mouse, Wireless Mouse, Mouse

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.