



# SUN2SOLAR 902518A Solar Heater Bypass Kit Instruction Manual


[Home](#) » [SUN2SOLAR](#) » SUN2SOLAR 902518A Solar Heater Bypass Kit Instruction Manual 



## Contents

- [1 INSTRUCTIONS](#)
- [2 Bypass Kit Includes](#)
- [3 Bypass Valve Control](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)

## INSTRUCTIONS




1. Turn off filter/pump then block off water from the pool at filter/pump and pool return connections.
2. Disconnect pool return hose from the filter/oump.
3. To install bypass kit:
  - a. Apply Teflon tape to the threading and then thread bypass fittings into the bypass valve.
  - b. Connect solar heaters as shown in figure using included hoses and hose clamps.
- Hint:** Using caution, dip ends of flex hose in hot water (not boiling) to help fit "T" connector.
4. Unlock water and turn on filter/pump.
5. Adjust bypass valve as needed to achieve desired flow.

## Bypass Kit Includes


- 1 – Bypass Valve
- 1- "T" Connector
- 3-14"/1/2" Threaded Bypass Fittings
- 1-1½" x 72" Flex Hose
- 6 – Stainless Steel Hose Clamps
- 1 – Teflon Tape

## Bypass Valve Control



#902518A

## Documents / Resources



[SUN2SOLAR 902518A Solar Heater Bypass Kit](#) [pdf] Instruction Manual  
902518A Solar Heater Bypass Kit, 902518A, Solar Heater Bypass Kit, Heater Bypass Kit, Bypass Kit, Kit

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.