



suncast BMDB1310 Elements End Table with Storage Instructions

[Home](#) » [suncast](#) » suncast BMDB1310 Elements End Table with Storage Instructions

Contents [[hide](#)]

- [1 suncast BMDB1310 Elements End Table with Storage](#)
- [2 INSTALLATION INSTRUCTION](#)
- [3 demission](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



suncast BMDB1310 Elements End Table with Storage



INSTALLATION INSTRUCTION


- **STORAGE VOLUME:**

- 13 Gallons (1.75 Cubic Ft.)


- **LID LOAD:**

- Not to exceed 250 lbs.



demimission



Section A-A




Section B-B



- BATAVIA, IL 60510
- USA |630.879.2050
- WWW.SUNCAST.COM
- (C) SUNCAST CORPORATION
- ALL RIGHTS RESERVED

Documents / Resources

	suncast BMD1310 Elements End Table with Storage [pdf] Instructions BMD1310 Elements End Table with Storage, BMD1310, Elements End Table with Storage, Storage, Elements End Table, End Table, Table
---	--

References

- [S Home page - Suncast® Corporation](#)