



SUNGROW SG33CX CX String Inverter User Guide

[Home](#) » [SUNGROW](#) » SUNGROW SG33CX CX String Inverter User Guide 

SUNGROW SG33CX CX String Inverter



Contents

- [1 April.25th , 2022 Feature Update](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

April.25th , 2022 Feature Update

Valid till: April.25th, 2023

Firmware:

SG33CX/40/CX50CX

Installation package: AGATE-S_B000.V000.P008-20220307 or above

Detail version: AGATE-S_03011.01.28 & AGATE-S_01011.01.28 or above

SG110CX

Installation package: AMBER-S_B000.V000.P006-20220226 or above

Detail version: AMBER-S_03011.01.18 & AMBER-S_01011.01.20 or above

Updated log:

SG33CX/40/CX50CX

- Grid code update
 - a) Spain: Spain (ES) NTS 631
 - b) Poland: Poland (PL) NC RfG PSE:2018
 - c) Sweden: Sweden (SE) EIFS 2018:2-EnergiForetagen
 - d) Austria: removed since the new generation SGxxCX-P2 will cover Austria

SG110CX

- **Grid code update**
 - a) Sweden: Sweden (SE) EIFS 2018:2-EnergiForetagen Type A and Type B
 - b) Austria: removed since the new generation SGxxCX-P2 will cover Austria



Documents / Resources

 CX String Inverter SG33CX / SG40CX / SG50CX / SG110CX Features Update	SUNGROW SG33CX CX String Inverter [pdf] User Guide SG33CX, SG40CX, SG50CX, SG110CX, SG33CX CX String Inverter, CX String Inverter, String Inverter, Inverter
--	---