





# sunlu S4 3D Upgrade Storage Saving Arid Machine User Guide

Home » SUNLU » sunlu S4 3D Upgrade Storage Saving Arid Machine User Guide 1

#### **Contents**

- 1 sunlu S4 3D Upgrade Storage Saving Arid Machine
- **2 PRODUCT INFORMATION**
- 3 Product Parts Description
- 4 Usage Steps
- **5 Touch Screen**
- **6 Packing Listing**
- 7 Temperature Reference
- **8 CONTACT INFORMATION**
- 9 Documents / Resources
  - 9.1 References



sunlu S4 3D Upgrade Storage Saving Arid Machine



## **PRODUCT INFORMATION**

## **Foreword Vorwort**

- Thank you for using SUNLU products!
  - If you have any questions about this product, please contact the customer service of the official store where you purchased it.
  - Please read this manual carefully to avoid wrong installation and use. Scan the QR code on the cover to download detailed instructions for use.

## **Product Parts Description**



- 1 3 5: Filament outlet
- 2: Control Panel Top Cover (0 Power Input
- 4: Top Cover
- 6: Power Input

## **Usage Steps**


• Step 1 Insert the Teflon tube into the filament outlet according to the picture.



• Step 2 Open the top cover and put the filament into the dryer box.




• Step 3 Thread the filament through the filament output of the filament dryer and the Teflon tube.




• Step 4 Connect the power supply and press the switch.



**Touch Screen** 






- Modes
  - MO 1 Time control mode (shut down after countdown)
  - MO 2 Humidity control mode (after the countdown ends, when the humidity slowly rises to 50% or the User-set humidity value, it will automatically start heating until the humidity drops to 25%)

**Note:** If the humidity does not decrease to the target value, please check whether the top cover is properly closed, or appropriately increase the set heating temperature by 5°C.

## **Packing Listing**



## **Temperature Reference**

Material (Material)	PLA/ PLA+	WOOD	PETG	PVB	ABS/ ABS+	HIPS	PVA	ASA	TPU	РММА	PA/PC
Baking Temp (Backtemperatur)	45-50°C				50-55*C						60-70°C
Time (Zel0	3-6h										

## **CONTACT INFORMATION**

• Enjoy 3D Printing with SUNLU



• Zhuhai Sunlu Industrial Co., Ltd.

• Official website: www.3dsunlu.com

• Brand cooperation: branding@sunlu.com

• Business cooperation: sales@sunlu.com

After-sales service: <u>support@sunlu.com</u>

• Address: No. 38, Yongtian Road, Sanxi Science and Innovation Town,

- Xiangzhou District, Zhuhai City, Guangdong Province, China
- Please scan the QR code to download the detailed manual



#### **Documents / Resources**



<u>sunlu S4 3D Upgrade Storage Saving Arid Machine</u> [pdf] User Guide
S4 3D Upgrade Storage Saving Arid Machine, S4 3D, Upgrade Storage Saving Arid Machine, S
torage Saving Arid Machine, Saving Arid Machine, Arid Machine, Machine

#### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.