



Sunrise ACL-201 Digital Alarm Clock with LCD Display and Indoor Thermometer User Manual

[Home](#) » [Sunrise](#) » Sunrise ACL-201 Digital Alarm Clock with LCD Display and Indoor Thermometer User Manual



SUNRISE



Clock with LCD Display and Indoor Thermometer
User Manual



Contents

- 1 BATTERY INSTALLATION
- 2 TIME SETTING
- 3 ALARM SETTING
- 4 CLOSING THE ALARM
- 5 ALARM ON (AT THE TIME THAT IT WAS PROGRAMMED PREVIOUSLY)
- 6 SETTING BIRTH REMINDER
- 7 Documents / Resources
- 8 Related Posts

BATTERY INSTALLATION

1. Open the battery compartment cover at the rear side of the clock.
2. Insert 2 x AM batteries (not included) following the polarity marks “+” and “-”.
3. Please follow correct polarity according to the markings.

NOTE:

- Do not mix new and old batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

TIME SETTING

- Press the “MODE” button and the 12/24 hour mode display will start to flash. Now use the “▲” and “▼” buttons to set the 12/24 hour format. Press “SET” to confirm your setting.
- The Hour display will start to flash. Now use the “▲” and “▼” buttons to set the hour. Press “SET” to confirm your setting.
- The Minute display will start to flash. Now use the “▲” and “▼” buttons to set the minutes. Press “SET” to confirm your setting.
- The Year display will start to flash. Now use the “▲” and “▼” buttons to set the year. Press “SET” to confirm your setting.
- The Month display will start to flash. Now use the “▲” and “▼” buttons to set the correct month. Press “SET” to confirm your setting.
- The Date display will start to flash. Now use the “▲” and “▼” buttons to set the correct date. Press “SET” to confirm your setting.

ALARM SETTING

1. Press the “MODE” key twice or press the “ALM” key directly to enter into the alarm mode.
2. Press the “SET” key to set Hour, Minute, Ringtone and adjust them by pressing “▲/▼” key.
3. At normal time display status, with the “ALARM” word display, press “▲” key to activate the SNOOZE function and press again to close the SNOOZE function.
4. If the alarm is ON and the snooze function in OFF, the alarm will ring for one minute when the clock rings. Press any key to stop. If both of them are ON, it will ring for one minute every four minutes interval.

5. At the activating status of snooze & alarm, press any key to stop the alarm and turn on the snooze function with SNZ icon flashing or canceled by press “▲” key.

CLOSING THE ALARM

1. Press the “MODE” key repeatedly until you enter the alarm mode or press the “ALM” key directly.
2. Press the “SET” key to set the time, minute, and alarm sound setting. At the fourth press of the “SET” key, no field will blink. At the fifth press of the “SET” key, “_:” will appear on the display. This means that the alarm is off. Press the mode key repeatedly until you enter the time mode. The alarm will not be displayed on the screen, which means that the alarm is disabled.

ALARM ON (AT THE TIME THAT IT WAS PROGRAMMED PREVIOUSLY)

1. To reset the alarm (at the time that was programmed previously), press the “MODE” key repeatedly until you enter alarm mode.
2. Press the “SET” key and the last programmed alarm time will be displayed. Time will start to flash (if you do not press “▲/▼” keys, the alarm time will remain the same, and if you press the “▲/▼” keys the time will be changed).
3. Press the “MODE” key repeatedly until you enter the time mode. The alarm will be displayed on the screen, which means that the alarm is enabled.

SETTING BIRTH REMINDER

1. At the normal display status, press the “MODE” key three times into the birthday-reminding setting mode.
2. Press the “SET” key to set Hour, Minute, Year, Month, Date by step with the “▲/▼” key.
3. Once the birthday-reminding rings, it will play a birthday song for 5 minutes automatically to congratulate “HAPPY BIRTHDAY”.
4. To turn off the alarm, press one “ALM” key. When the alarm time is displayed, press the “SET” key until “_:” appears in the display. Then, press twice the “MODE” key. The current time will be displayed on the screen without the ALARM sign at the top. The alarm has been turned off.

SUNRISE

Ionias Kalochori, 570 09 Thessaloniki, Greece,
TEL. +30 2310 700.777
e-mail: info@sun.gr
www.sun.gr



Made in China



[Sunrise ACL-201 Digital Alarm Clock with LCD Display and Indoor Thermometer](#) [pdf] Use
r Manual
ACL-201, Digital Alarm Clock with LCD Display and Indoor Thermometer, ACL-201 Digital Alarm
Clock with LCD Display and Indoor Thermometer