




SUNSKY C360 2K Network High-Definition Computer Camera User Manual

[Home](#) » [sunsky](#) » SUNSKY C360 2K Network High-Definition Computer Camera User Manual 

SUNSKY C360 2K Network High-Definition Computer Camera





Contents

- [1 Product Parameter](#)
- [2 Get started](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Product Parameter


Sensor: HD CMOS Sensor
Lens: 6G SM lens F3.6
DSP: High Speed Controller
Video Recording: AVI, CIF Mode
Frame Rate: 30 f/s (600 Lux)
Interface: USB 2.0 & USB 1.1 compatible
Power Supply: 5V (USB port)
Resolution : **X2560X1440**
Material: ABS plastic, Nanometer lens
Wire material: 1.8 meters fine copper
Microphone: High quality integrated USB Mic, 10 meters effective distance

Frame rate: Max. 30 FPS under VGA format
Output format: USB 2.0 uncompressed YUY2
Plug: USB 2.0 High Speed (Isochronous)
Imaging distance: 50mm to infinity
Flicker control: 50HZ
Static picture storage format: BMP/JPG
Dynamic picture storage format: AVI

Get started

1. Plug it into one of the USB ports of your computer. If you are using a desktop PC, it will be better to plug it into the USB ports at the back of computer case instead of those in the front.

Documents / Resources

	SUNSKY C360 2K Network High-Definition Computer Camera [pdf] User Manual C360, 2K Network High-Definition Computer Camera
---	--

