

SunTouch 500120 ConnectPlus Smart Sensor User Manual

Home » SunTouch » SunTouch 500120 ConnectPlus Smart Sensor User Manual



SunTouch 500120 ConnectPlus Smart Sensor



Contents

- 1 SunTouch® ConnectPlus™ Smart Sensor
 - 1.1 Description
 - 1.2 Where to Use
 - 1.3 Specifications
 - 1.4 Setup
 - 1.5 Limited 3 Year Warranty
- 2 ConnectPlus™ Smart Sensor
 - 2.1 Specifications
 - 2.2 Status Indicators
 - 2.3 CUSTOMER SERVICES
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**

SunTouch® ConnectPlus™ Smart Sensor

Description

The ConnectPlus™ Smart Sensor is a temperature and water leakage sensor that pairs to the ConnectPlus thermostat. This device can be used as an optional floor temperature sensor for the radiant floor heating system. Detected water leaks produce audible and visual alarms, and notifications are transmitted to the thermostat.

Where to Use

Temperature Sensor

Place the Smart Sensor directly on a heated section of the floor to use as a floor control sensor.

Water Leakage Sensor

Place the Smart Sensor directly on the floor where there is a risk of water leakage (near water lines, washing machines, hot water tanks, ...) within range of the ConnectPlus thermostat.

Specifications

• Power: 2 x AA batteries included

• Battery Life: 1 year

Range: 75 ft, line-of-sightPairing limit: 6 devices

- I aming miner o dovidoo

• Operating Temperature range : 32°F to 104°F (0°C to 40°C)

• Operating Humidity range: 0 to 100% humidity

• Storage temperature range : -4°F to 122°F (-20°C to 50°C)

• IP Waterproof Class: IP67

• Diameter 33/8" (85mm), Height 111/16" (43mm)






Please read carefully before proceeding with installation.


Your failure to follow any attached instructions or operating parameters may lead to the product's failure. Keep this Manual for future reference


Setup





Power 2 X AA Batteries





Sensors are located on the bottom

Wireless Pairing:

- Put the ConnectPlus into pairing mode: Menu > Settings > Paired Devices > Pair Device
- Press and hold button on the Smart Sensor for 3 seconds Wake: short button press

Status Indicators

Not paired Orange blink
Pairing Orange blink
Paired Green steady
Water Leak Red/Green blink & buzzer
Error Red steady
Low Battery Red blink

Pairing Mode: hold the button down for 3 sec (30 sec timeout)

Silence Buzzer: short button press

Limited 3 Year Warranty

SunTouch warrants this control (the product) to be free from defect in material and workmanship for a period of (3) years from the date of original purchase from authorized dealers.

During this period, SunTouch will replace the product or refund the original cost of the product at SunTouch's option, without charge, if the product is proven defective in normal use.

Please return the control to your distributor to begin the warranty process.

This limited warranty does not cover shipping costs. Nor does it cover a product subjected to misuse or accidental damage. This warranty does not cover the cost of installation, diagnosis, removal or reinstallation, or any material costs or loss of use.

This limited warranty is in lieu of all other warranties, obligations, or liabilities expressed or implied by the company. In no event shall SunTouch be liable for consequential or incidental damages resulting from installation of this product. Some states or provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

ConnectPlus™ Smart Sensor


The ConnectPlus™ Smart Sensor is a temperature and water leakage sensor that pairs to the ConnectPlus thermostat. This device can be used as an optional floor temperature sensor for the radiant floor heating system. Detected water leaks produce audible and visual alarms, and notifications are transmitted to the thermostat.



ConnectPlus Smart Sensor

Specifications

Literature	IOM-ST-CPSS, ES-ST-CPSS	
Power	2 x AA Batteries Included	
Battery Life	1 Year	
Operating Temperature	32°F to 104°F (0°C to 40°C)	
Operating Humidity Range	0 to 100% humidity	
Storage Range	-4°F to 122°F (-20°C to 50°C)	
IP Waterproof Case	IP67	
Dimensions	Diameter 33 /8" (85.38mm), Height 111/16" (42.87mm)	



NOTICE

The ConnectPlus Smart Sensor is only compatible with the SunStat® ConnectPlus model. Does not connect to older model SunStat thermostats.

Status Indicators

Not paired Orange blink
Pairing Green blink
Paired Green steady
Water Leak Red/Green blink & buzzer
Error Red steady
Low Battery Red blink

FCC ID: 2AFJT – CIMDOF18815 **IC:** 20938 – CIMDOF18815



This Engineering Sheet is not intended to provide full installation instructions and safety information. In order to avoid property damage or injury, please refer to the complete installation manual and product safety information provided with the product.

Qty	Description	Model#	Order#
	ConnectPlus Smart Sensor	500120	81020611

SunTouch product specifications in U.S. customary units and metric are approximate and are provided for reference only. For precise measurements, please contact SunTouch Technical Service. Suntouch reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on SunTouch products previously or subsequently sold. Refer to the owner's manual for warranty information.

CUSTOMER SERVICES

USA: T: (888) 432-8932 • **F:** (417) 831-4067 • **SunTouch.com**

Canada: T: (888) 208-8927 **F:** (905) 481-2316

Latin America: T: (52) 55-4122-0138

• SunTouch.com

ES-ST-ConnectPlus Smart Sensor 2128 © 2021 Watts



A WATTS Brand

Documents / Resources



<u>SunTouch 500120 ConnectPlus Smart Sensor</u> [pdf] User Manual

500120 ConnectPlus Smart Sensor, 500120, ConnectPlus Smart Sensor, Smart Sensor, Sensor

References

• **SunTouch** | Radiant Floor Heating & Snow Melting Systems

Manuals+,