

superbrightleds com LDL Series Flexible Gooseneck Dock Light User Manual

Home » superbrightleds com » superbrightleds com LDL Series Flexible Gooseneck Dock Light User Manual



User Manual LDL Series

Important: Read all instructions prior to installation.

Flexible Gooseneck Dock Light

Contents

- 1 LDL Series Flexible Gooseneck Dock
- Light
- 2 Safety and Notes
- 3 Specifications
- **4 Installation Instructions**
- 5 Documents / Resources
- **6 Related Posts**

LDL Series Flexible Gooseneck Dock Light



Safety and Notes

- Product should be installed and serviced in accordance with applicable national, state, and local building and electrical codes.
- · Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture. Failure to properly support fixture may result in damage or injury, for which the manufacturer does not assume responsibility.

Specifications


Environmental Specifications	
Operating Temperature	-31°–131° F (-35°–55° C)
IP Rating	IP65*


^{*}IP65 rating requires connection to weather protected outlet.

Check product label for specific electrical specifications related to installation. Improper installation will void warranty.

Installation Instructions

- 1. Open housing by unscrewing both side thumbscrews.
- 2. Drill mounting holes into surface. Lightly thread top two screws into mounting holes. Slide fixture over mounting screw and tighten to secure. Secure to surface using the bottom two screws.
- 3. Connect 5-15P plug into weather protected outlet.






Rev Date: V1 04/14/2022 4400 Earth City Expy, St. Louis, MO 63045 866-590-3533 <u>superbrightleds.com</u>



Documents / Resources



superbrightleds com LDL Series Flexible Gooseneck Dock Light [pdf] User Manual LDL Series Flexible Gooseneck Dock Light, LDL Series, Flexible Gooseneck Dock Light, Gooseneck Dock Light, Light

Manuals+,