Manuals+ — User Manuals Simplified.

SUPERNOTE A6-X2 C Nomad Back Teaser User Manual

Contents

SUPERNOTE A6-X2 C Nomad Back Teaser

Product Information

Specifications

- Model: SUPERNOTE A6 X2-C
- Battery Capacity: 5.0 V 2.0 A
- IC: 24370-A6X2
- HVIN: A6-X2C
- FCC ID: 2AQZ9-A6-X2
- Made in China
- 5 GHz band (W52): Indoor use only

Product Usage Instructions

Charging

To charge the device, follow these steps:

1. Connect the device to a power source using the provided charging cable.
2. The input voltage should be 5.0 V and the input current should be 2.0 A.
3. Ensure that the device is properly connected and the charging indicator light turns on.
4. Wait until the battery is fully charged before disconnecting the device from the power source.

Body Worn Operation

When using the device in body worn operation, please note the following guidelines:

- The device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

- Ensure that the accessory positions the device a minimum of 0 mm from the body to comply with RF exposure guidelines.

Frequently Asked Questions (FAQ)

What is the SAR information for this device?

The Specific Absorption Rate (SAR) information for this device is as follows:

FCC Device: The device meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

ISED Device: The device meets the ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

Documents / Resources

SUPERNOTE A6-X2 C Nomad Back Teaser [pdf] User Manual
A6-X2 C Nomad Back Teaser, A6-X2 C, Nomad Back Teaser, Back Teaser, Teaser

References

- **User Manual**