



Supra How to Change the Shackle Code Using the Ekey® App Instructions

[Home](#) » [Supra](#) » Supra How to Change the Shackle Code Using the Ekey® App Instructions 

Contents

- [1 Supra How to Change the Shackle Code Using the Ekey® App](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)



Supra How to Change the Shackle Code Using the Ekey® App




Open a Supra® iBox BT or iBox BT LE with your Android™ or Apple® Device

To open a Bluetooth® keybox

- Open the Supra eKEY app and tap the Obtain Key icon on your device.
- Press up on the bottom of the keybox to turn on its Bluetooth®. A red-purple light on the keybox lens flashes to show the Bluetooth is on and ready. *If you are using an eKEY Fob, do not turn the Bluetooth on. Instead, point the eKEY Fob at the keybox lens.
- After entering a 4-digit PIN, the eKEY app will start communicating with the keybox.
- When eKEY app displays "Success!," press up on the bottom of the keybox to release the key container.

Keybox lens




Press up until the red light flashes to turn on the Bluetooth

All Apple products must use an eKEY Fob to communicate with iBox BT keyboxes.

How to Change the Shackle Code using the eKEY® App

Open the shackle first to change the shackle code.



Open the Shackle

1. Open the eKEY app.
2. Tap the Open Shackle icon.
3. Enter the 4-digit shackle code.
4. Tap a Reason for shackle release.
5. If you are using an eKEY Fob, point it at keybox lens.
6. For Bluetooth, press up on the bottom of the keybox to turn it on. For infrared, turn on the eKEY Fob and point it at the lens on the keybox.
7. Tap Begin.
Upon success, press down on the top of the shackle to release.

Tap circle to add to keybox inventory (My Keyboxes)

Change the Shackle Code

Note: Keybox must be in eKEY inventory (My Keyboxes).

1. Tap My Keyboxes.
2. Tap the relevant keybox.
3. Tap Program Keybox.
4. Under Keybox Settings, tap Shackle Code.
5. Enter a new shackle code and enter it again to confirm.
6. Tap Save.
7. Tap Program.
8. Enter the old shackle code.
9. When the Success! message appears, tap Home icon to return to main menu.

supraekey.com

800-547-0252 • © 2020. Carrier. All Rights Reserved. Supra is part of Carrier..



[Supra How to Change the Shackle Code Using the Ekey® App](#) [pdf] Instructions

How to Change the Shackle Code Using the Ekey App