

# Suprema Secure I/O 2 Access Control System Accessory **Installation Guide**

Home » suprema » Suprema Secure I/O 2 Access Control System Accessory Installation Guide 🖺



#### Contents

- 1 Suprema Secure I/O 2 Access Control System **Accessory**
- 2 Safety information
- 3 Introduction
- **4 Product Specifications**
- **5 Dimensions**
- **6 FCC compliance information**
- 7 Appendices
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts



Suprema Secure I/O 2 Access Control System Accessory



## **Product Specifications**

• Model: Secure I/O 2

• Version: 2.14

· Language: English

# Installation Guide Safety Information

Warning: Please read the safety instructions carefully to prevent injury and property damage.

Caution: Follow the manual instructions for a safe installation.

#### **Installation Instructions**

#### Installation

- · Avoid miswiring with high-capacity power supply.
- Do not install or repair the product arbitrarily.
- Avoid direct sunlight, moisture, dust, soot, or gas leaks during installation.
- Keep away from heat sources like electric heaters.
- Place the product in a dry location away from radio frequencies.

## Operation

- Keep the product dry and avoid using damaged power supply adapters.
- Do not bend or damage the power cord.
- Avoid cutting off power during firmware upgrades.

### **Connection Instructions**

Ensure all wiring is done with power turned off for safety. Use approved power adapters and independent power sources for Secure I/O 2.

#### **Cleaning Instructions**

Clean exposed surfaces including the fingerprint sensor with rubbing alcohol and a non-abrasive cloth. Do not use for purposes other than intended.

## Frequently Asked Questions (FAQ)

#### Q: Can Secure I/O 2 be used outdoors?

A: It is recommended to install Secure I/O 2 in a dry location away from direct sunlight and moisture.

## Safety information

Please read this safety instructions before you use the product to prevent injury to yourself and others and to prevent property damage. The term 'product' in this manual refers to the product and any items provided with the product.

#### Instructional icons

Warning: This symbol indicates situations that could result in death or severe injury.

Caution: This symbol indicates situations that may result in moderate injury or property damage.

Note: This symbol indicates notes or additional information.

## Warning

#### Installation

When using a high-capacity power supply, please pay special attention to avoid miswiring.

• Miswiring may result in serious fire, electric shock, or product damage.

#### Do not install or repair the product arbitrarily.

- This may result in electric shock, fire, or product damage.
- Damages caused by any modifications or failure to follow installation instructions can void the manufacturer's warranty.
- Do not install the product in a place with direct sunlight, moisture, dust, soot, or a gas leak.
- This may result in electric shock or fire.

#### Do not install the product in a location with heat from an electric heater.

- This may result in fire due to overheating.
- Install the product in a dry location.
- Humidity and liquids may result in electric shock or product damage.

#### Do not install the product in a location where it will be affected by radio frequencies.

This may result in fire or product damage.

## Operation

- Keep the product dry.
- Humidity and liquids may result in electric shock, fire, or product damage.

## Do not use damaged power supply adapters, plugs, or loose electrical sockets.

- Unsecured connections may cause electric shock or fire.
- Do not bend or damage the power cord.
- This may result in electric shock or fire.

#### Caution

#### Installation

Please read this manual before installing the product to ensure a safe and correct installation. When wiring the power cable and other cables, make sure to connect them with the power turned off for all devices involved.

- The product may malfunction.
  - Before connecting power to the product, double-check the manual to ensure that the wiring is correct, then connect the power.
  - Do not install the product in a place where it is exposed to direct sunlight or UV light.
- This may cause product damage, malfunction, discoloring or distortion.

## Do not install the power supply cable in a location where people pass by.

- This may result in injury or product damage.
   Do not install the product near magnetic objects, such as a magnet, TV, monitor (especially CRT), or speaker.
- The product may malfunction.

# Use the IEC/EN 62368-1 approved power adapter that supports higher power consumption than the product.

It is highly recommended to use the power adapter sold by Suprema.

- If the right power supply is not used, the product may malfunction.
- Refer to the Power in the product specifications for maximum current consumption specifications.

## Secure I/O 2, the electrical locking device and access controller must use independent power source.

The product may malfunction.

## Operation

- Do not drop the product or cause impacts to the product.
- The product may malfunction.

#### Ensure that the power is not cut off when a product firmware upgrade is in progress.

The product may malfunction.

Do not press buttons on the product by force or do not press them with a sharp tool.

• The product may malfunction.

Use the product at a temperature of -20  $^{\circ}$ C to 50  $^{\circ}$ C. Do not keep the product at an extremely low or high temperature.

• The product may malfunction.

## When cleaning the product, mind the following.


- Wipe the product with a clean and dry towel.
- If you need to sanitize the product, moisten the cloth or the wipe with a proper amount of rubbing alcohol and gently clean all exposed surfaces including the fingerprint sensor. Use rubbing alcohol (containing 70% Isopropyl alcohol) and a clean, non-abrasive cloth like lens wipe.
- Do not apply liquid directly to the surface of the product.


#### Do not use the product for anything other than its intended use.

• The product may malfunction.


## Introduction

## Components






## Name of each part



Press INIT button to reset Secure I/O 2 interworking with a device and then connect to another device.

## **Installation Example**

Secure I/O 2 is connected with RS-485 and can be installed anywhere due to its small size. It can be installed with a junction box or onto a wall control box already installed. It can be installed at the rear side of an Exit button.




#### **Connections**


- Cable should be AWG22~AWG16.
- To connect the cable to Secure I/O 2, strip off approximately 5~6 mm of the end of the cable and connect hem.

#### **Power**

- Do not share the power with the access controller.
- Use the IEC/EN 62368-1 approved power adapter that supports higher power consumption than the product. If
  you wish to connect and use another device to the power supply adapter, you should use an adapter with a
  current capacity which is the same or larger than the total power consumption required for the terminal and
  another device.
  - Refer to the Power in the product specifications for maximum current consumption specifications.
- DO NOT extend the length of power cable when using the power adapter.




- RS-485 should be twisted pair, and maximum length is 1.2 km.
- Connect a termination resistor (120Ω) to both ends of a RS-485 daisy chain connection. It should be installed at both ends of the daisy chain. If it is installed in the middle of the chain, the performance in communicating will deteriorate because it reduces the signal level.



## Relay Fail Safe Lock


In order to use the Fail Safe Lock, connect the N/C relay as shown in the figure below. There is normally a current flowing through the relay for the Fail Safe Lock. When the relay is activated, blocking the current flow, the door will open. If the power supply to the product is cut off due to a power failure or an external factor, the door will open. Connect a diode to both ends of the power input as shown in the figure below when installing a deadbolt or a door strike. Make sure to connect the Cathode (direction to the stripe) to the + part of the power while paying attention to the direction of the diode.



#### **Fail Secure Lock**


In order to use the Fail Secure Lock, connect N/O relay as shown in the figure below. There is normally no current flowing through the relay for the Fail Secure Lock. When the current flow is activated by the relay, the door will open. If the power supply to the product is cut off due to a power failure or an external factor, the door will lock.

Connect a diode to both ends of the power input as shown in the figure below when installing a deadbolt or a door strike. Make sure to connect the Cathode (direction to the stripe) to the + part of the power while paying attention to the direction of diode.




## **Door button**

## **Door button**




## Door sensor



# **Product Specifications**

Category	Feature	Specification
	Model	SIO2
	CPU	Cortex M3 72 MHz
	Memory	128 KB Flash + 20 KB RAM
		Multi-color
	LED	• PWR
		• RS-485 TX/RX
		• IN1/IN2
		• RELAY
General	Operating Temperature	-20 °C ~ 50 °C
	Storage Temperature	-40 °C ~ 70 °C
	Operating Humidity	0 % ~ 80 %, non-condensing
	Storage Humidity	0 % ~ 90 %, non-condensing
	Dimension (W x H x D)	36 x 65 x 18 (mm)
	Weight	37 g
	Certificates	CE, UKCA, KC, FCC, RoHS, REACH, WEEE
interface	RS-485	1 ch
	RS-485 Communication Protocol	OSDP V2 compliant
	TTL Input	2 ch
	Relay	1 Relay
Electrical	Power	Voltage: 12 Vdc Current: Max. 0.5 A
	Relay	2 A @ 30 VDC Resistive load 1 A @ 30 VDC Inductive load

# **Dimensions**



## FCC compliance information

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.
  - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.
  - Modifications: Any modifications made to this device that are not approved by Suprema Inc. may void the authority granted to the user by the FCC to operate this equipment.

## **Appendices**

#### **Disclaimers**

- Information in this document is provided in connection with Suprema products.
- The right to use is acknowledged only for Suprema products included in the terms and conditions of use or sale for such products guaranteed by Suprema. No license, express or implied, by estoppel or otherwise, to any

intellectual property is granted by this document.

- Except as expressly stated in an agreement between you and Suprema, Suprema assumes no liability whatsoever, and Suprema disclaims all warranties, express or implied including, without limitation, relating to fitness for a particular purpose, merchantability, or noninfringement.
- All warranties are VOID if Suprema products have been: 1) improperly installed or where the serial numbers, warranty date or quality assurance decals on the hardware are altered or removed; 2) used in a manner other than as authorized by Suprema; 3) modified, altered, or repaired by a party other than Suprema or a party authorized by Suprema; or 4) operated or maintained in unsuitable environmental conditions.
- Suprema products are not intended for use in medical, lifesaving, life-sustaining applications, or other applications in which the failure of the Suprema product could create a situation where personal injury or death may occur. Should you purchase or use Suprema products for any such unintended or unauthorized application, you shall indemnify and hold Suprema and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Suprema was negligent regarding the design or manufacture of the part.
- Suprema reserves the right to make changes to specifications and product descriptions at any time without notice to improve reliability, function, or design.
- Personal information, in the form of authentication messages and other relative information, may be stored
  within Suprema products during usage. Suprema does not take responsibility for any information, including
  personal information, stored within Suprema's products that are not within Suprema's direct control or as stated
  by the relevant terms and conditions. When any stored information, including personal information, is used, it is
  the responsibility of the product users to comply with national legislation (such as GDPR) and to ensure proper
  handling and processing.
- You must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Suprema reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.
- Except as expressly set forth herein, to the maximum extent permitted by law, the Suprema products are sold "as is".
- Contact your local Suprema sales office or your distributor to obtain the latest specifications and before placing your product order.

#### **Copyright Notice**

Suprema has the copyright of this document. The rights of other product names, brands, and trademarks belong to individuals or organizations who own them.

#### Suprema Inc.

17F Parkview Tower, 248, Jeongjail-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, 13554, Rep. of KOREA Tel: +82 31 783 4502 | Fax: +82 31 783 4503 | Inquiry: <a href="mailto:sales\_sys@supremainc.com">sales\_sys@supremainc.com</a>

For more information about Suprema's global branch offices, visit the webpage below by scanning the QR code. <a href="http://www.supremainc.com/en/about/contact-us.asp">http://www.supremainc.com/en/about/contact-us.asp</a>



© 2024 Suprema Inc. Suprema and identifying product names and numbers herein are registered trade marks of Suprema, Inc. All non-Suprema brands and product names are trademarks or registered trademarks of their respective companies.

Product appearance, build status and/or specifications are subject to change without notice.

#### **Documents / Resources**



<u>Suprema Secure I/O 2 Access Control System Accessory</u> [pdf] Installation Guide Secure IO 2 Access Control System Accessory, Secure IO, 2 Access Control System Accessory, Control System Accessory, Accessory

## References

- Suprema | Security & Biometrics
- User Manual

## Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.