

Surplife A-SL-05 String Lights User Manual

Home » Surplife » Surplife A-SL-05 String Lights User Manual

Contents

- 1 Surplife A-SL-05 String Lights
- 2 Installation
- 3 How to Connect to Surplife

App

- **4 Remote Control**
- **5 FCC WARNING:**
- **6 Frequently asked Questions**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**




Surplife A-SL-05 String Lights



Installation

Connection Schematic Diagram

Hang the hooks onto the hooks of curtain, or hooks on the wall. If no hooks, please try to find ways to solid the hooks of our curtain lights at the place you'd like to use.



- 1. Check product list from package, make sure everything's clear.
- 2. Hang products in right ways.
- 3. Check power supply and know how to turn on/off, 8 seconds long press to restart original settings.


Download Surplife APP

Download "Surplife" in App Store, register and make sure Bluetooth of mobile phone is turned on.




How to Connect to Surplife App


Register/Login your Surplife account.



Enter "Surplife" app, tap "add device" or click "+" to add the device.



Rename the device and select a room for it.



Remote Control



FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.


Frequently asked Questions

How to set up your Bluetooth LED string light?

- Enable your Bluetooth on your phone.
- Then power on the LED string light.
- Open "Surplife" App, the App can directly connect to the device. It can automatically match the light without other steps, and you can experience the smart light simply and quickly.

How can I do if connecting the Bluetooth device or adding new device failed?

Please power off the led string light, then turn it on again, if the problem can't solve, please restart the phone.



Documents / Resources



<u>Surplife A-SL-05 String Lights</u> [pdf] User Manual A-SL-05 String Lights, A-SL-05, String Lights, Lights

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.