



Surtime Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP Instructions

[Home](#) » [SURTIME](#) » Surtime Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP Instructions 

Surtime

Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP Instructions

Contents

- [1 Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP](#)
- [2 Instructions](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP

Steps 1 :click “Add” to set the name of the fan light.

Steps 2 and then press the Pair code check button 1-2 times within 5 seconds after the fan is powered on.

Note: If your APP interface is displayed in Chinese, click the menu in the upper right corner to switch languages



Instructions



Pair button. In order to ensure that the application can successfully control the device, please click this button within 5 seconds after the device is powered on. If the device flashes or beeps, it means that the phone has been successfully paired with the device, and then the device can be controlled through the application, or beeps it means that the phone has been successfully paired with the device, and then the device can be controlled through the application.



Click to select a time to turn off the device



The wind blown by the fan after clicking is like the wind in nature



The wind blown by the fan after clicking is suitable for sleep.



The fan will rotate reverse after clicking.



Click to change the direction of the wind



The fan will rotate forward after clicking.



When you click, the white light and the yellow light will light up at the same time, but only at 10% of the maximum brightness




When clicked, the white light and yellow light will light at the same time, and the brightness will be the maximum brightness



When clicked, only yellow light will light up, and the brightness will be the maximum brightness



When clicked, only white light will light up, and the brightness will be the maximum brightness.



Unpair button. Click this button within 5 seconds when the device is powered on, If the device flashes or beeps, it means that the phone is unpaired with the device and the phone will not be able to control the device when in the room page, long press the device card you can delete the device or change the device name.

Surtime



<http://www.jasonghost.com/fanlamppro/>

Scan QR code and download APP
Support IOS and Android



[Surtime Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP](#) [pdf] Instructions

Low Profile Flush Mount Ceiling Fans with Lights and Remote and APP, Low Profile, Flush Mount Ceiling Fans with Lights and Remote and APP, Ceiling Fans with Lights and Remote and APP, Lights and Remote and APP, Remote and APP, APP

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.