



Home » SWH » SWH CDL-OK104 Pendent Lamp Instruction Manual 📆

SWH CDL-OK104 Pendent Lamp



WARNING SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

Contents [hide]

- 1 Product Description
- 2 Documents / Resources
 - 2.1 References

Product Description


Turn Off The Power

1. 1. Spread the arm to the left and right on the lamp body and adjust it to be evenly

distributed.


- 2. Put the cover on the part and tighten it.
- 3. Pass the power cord through the iron pipe, and then screw the iron pipe into the connector on the lamp body in sequence.
- 4. Install the movable buckle on the chain to the ring on the lamp body, and pass the wire through the chain, movable buckle, ceiling ring and ceiling plate.
- 5. Install the ceiling plate on the junction box (J-BOX) using the mounting screws.
- 6. Connect the lamp power cord to the mains using a wiring cap, and connect the lamp ground wire to the house ground wire using a wiring cap.
- 7. Secure the ceiling plate to the ceiling plate using the ceiling ring.
- 8. Install a rated wattage bulb (bulb not included).

Turn on the power



Please completely comply with this instructions and notes to ensure that the product is operated in a safe condition.

Documents / Resources



SWH CDL-OK104 Pendent Lamp [pdf] Instruction Manual

CDL-OK104 Pendent Lamp, CDL-OK104, Pendent Lamp, Lamp

References

•		lser	M	lan	ual
•	$\overline{}$	' '	IV	ıaıı	uui

SWH CDL-OK104, CDL-OK104 Pendent Lamp, lamp, Pendent Lamp, SWH

Save my name, email, and website in this browser for the next time I comment.

Your email address will not be published. Required fields are marked *

Leave a comment

Comment *	
Name	
Email	
Website	
TTOSOILO	

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.