



SZPACMATE WM-DINO Dino Egg Projector User Manual

[Home](#) » [SZPACMATE](#) » SZPACMATE WM-DINO Dino Egg Projector User Manual 

Contents

- [1 SZPACMATE WM-DINO Dino Egg Projector](#)
- [2 Specifications](#)
- [3 How to Use](#)
- [4 Manual Button Instruction](#)
- [5 Remote Controller Function Description](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

S Z P  A C M  A T E

SZPACMATE WM-DINO Dino Egg Projector



Specifications

- ITEM#WM-DINO
- Bluetooth® 5.1
- Material: ABS+AS
- Dinosaur Egg Galaxy Projector x1
- Remote Controller x1
- USB C Cable x1
- User Manual x1
- Base x1

Note:

1. Please operate in strict accordance with this user manual.
2. Never disassemble the device or its accessories.
3. Suitable for indoor use ONLY.


Please read the manual carefully before use, which includes the necessary safety tips and operating instructions. Please follow the instructions to avoid damage due to misuse.

How to Use

1. Project to the direction of the sky (on the ceiling) ideal for indoor use.
2. Operate as illustrated in the following figure to use the projector correctly.
3. Connects to your mobile device via Bluetooth “Jurassic Projector Speaker” so you can play music on it using a

Bluetooth speaker.

4. Use the remote controller correctly, ensuring that the remote controller points to the infrared sensor.




Manual Button Instruction

1. Projection Dynamic Key (switch between dynamic and static)
2. Conversion Key
3. Main Switch

Remote Controller Function Description

1. Switch
2. White Noise
3. Red Ambient Light Switch
4. Green Ambient Light Switch
5. Blue Ambient Light Switch
6. White Ambient Light Switch
7. Volume Up
8. Volume Down
9. Previous White Noise/Song
10. Next White Noise/Song
11. White Noise/Song Pause
12. Single-color light automatically rotates

13. Dual Color Selection Mode
14. Two-color light automatically changes in turn
15. Light Brightness Control
16. Sound Control Rhythm Mode
17. Flow Speed Control
18. 1 Hour Timing Setting: Short press the "1H" button, then "buzz" once as a reminder. The device will turn off automatically after one hour.
19. 2-Hour Timing Setting: Short press the "2H" button, then "buzz" once as a reminder. The device will turn off automatically after two hours.
20. Time Setting Cancel: Short press "RESET" button to cancel the time setting, then "buzz" once as a reminder.
21. Main Switch: Turn the Device On/Off



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.


This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment
This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.

Documents / Resources

	SZPACMATE WM-DINO Dino Egg Projector [pdf] User Manual OR0140-BT, 2A2WN-OR0140-BT, 2A2WNOR0140BT, WM-DINO, WM-DINO Dino Egg Project or, Dino Egg Projector, Egg Projector, Projector
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)