

# **T-LED DIGI04 WiFi Sound Control SPI Controller Instruction Manual**

Home » T-LED » T-LED DIGI04 WiFi Sound Control SPI Controller Instruction Manual





**Product Name:** Wi-Fi sound-control SPI controller(D series)

#### **Contents**

- **1 Product Parameter**
- 2 Key Functions
- 3 How to set the IC model and IC numbers
- 4 Detailed introduction of APP functions
- **5 ATTENTIONS**
- **6 Documents / Resources** 
  - **6.1 References**
- 7 Related Posts

# **Product Parameter**

Category	LED Controller	
Domination Principle	WiFi	
APP	Magic Home Pro	
Language	Chinese, English, Japanese, German	
Operation Platform	Android 4.0 or IOS 9.0 or higher	
LED Drive Type	SPI :WS2812B,WS2811,U CS1903,SK6812, SK6812RG BW,I N K100 3,UCS2904B	
In put Voltage	DC(S-24)V	
Max Output Power	144W	
Work For	LED Strip	
Connect Method	Common Anode	
Working Tern peratu re	-20~+55°C	
Control Distance	Visible distance 40M	
Certification	CE, RoHS, FCC	
Warranty	1 Year	
Net Weight	22g	
Dimension(L*B*H)	S0MM*34.SMM.19MM	

# **Key Functions**




- CS	Static colors switch	7 static colors switch (Red/ye I low/g reen/1 ig ht blue/dark blue/purple/white)
<b>3</b>	Static RGB	3 static colors switch (Red/Green/Blue)
(7)	7 static colors	7 static colors switch (Red/ye I low/g reen/1 ig ht blue/dark blue/purple/orange)
Auto	Loop mode	Built-in mode switch
M+ M-	Modes+/-	Bulit-in mode+/Bulit-in mode-
9999	DIY Mode 1-4	Hold down for two seconds to record the current mode, a nd short press to trigger the recorded mode next time.
1 2 3 4 no no no no	Jump/Breathing/Strobe/Running Water	4 different lighting effect which changes with the rhythm of external music

Note:

- 1. Remote control code matching: power on the device, hold down "ON" key for 5 seconds, the device flashes slowly to indicate successful code matching.
- 2. Remote code clearing: power on the device, hold down "OFF" key for 5 seconds, the device flashes quickly to indicate successful clearing
- 3. Scene mode can only record one custom color

# How to set the IC model and IC numbers


Long press the device and click on "Change LED Strip Type" to set the IC model, Wiring and Sorting, Number of points, Number of segment(Total number of points can not exceed 300 in each segment and total LED chip's quantity can not exceed 2048). On music mode, the total number of points in each segment and the total number of segment should be less than 150 points and 64 segments, the total LED Chip's quantity should be less than 960.



### **Detailed introduction of APP functions**

#### a) Fixed Mode

10 fixed modes are built in, can change foreground and background color, adjust brightness, speed and direction freely.



# b) Rbm Mode


100 patterns of change, slide the ring to select pattern effect, and slide "or "or "or overa II pattern effect brightness or speed settings. Click on "AUTO" to enter cycle mode or click on the heart icon to mark the favorite effect.



#### c)DIY Mode

Customized your own effects, click on "+" to choose your favorite effect and color then save it, now you can enjoy your own light effects at any time.

Ш



#### d) Music Mode


- 1. In the light screen mode, you can choose the falling color, column color, sensitivity and brightness, which can be played circularly to achieve a more beautiful light effect.
- 2. In the LED Strip Mode, you can select the brightness and sensitivity. There are two ways to input the audio

signal on the controller, built in APP microphone and extern a Im icrophone.




# e) Multi color function

1. Can set each IC seperately and set the lights with different modes 2. Optional dynamic modes for color lump gradient or mixed colors gradient:static, Asynchronous colors jumping, random color breathing, strobe and flow




2. The area where the camera is aimed at is the coloring area, and the light color will changed accordingly.



# f) Timer function

Smart lights automatically come on and off at given times through the timer function.



When setting the timer switch, you can select the color or dynamic mode and adjust the brightness and speed freely.








# g) Delay on/off function:

The lighting delay on/off time can be set according to personal preference





## **ATTENTIONS**

- 1. Please use the product in a dry environment.
- 2. Please use the in put voltage at 5-24V DC voltage, must not connect into 220V AC directly.
- 3. The product is requested common anode connection. The wrong connection will cause a malfunction.

#### **Documents / Resources**



T-LED DIGI04 WiFi Sound Control SPI Controller [pdf] Instruction Manual DIGI04 WiFi Sound Control SPI Controller, DIGI04, WiFi Sound Control SPI Controller, SPI Controller, Controller, Controller, Controller, Controller

# References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.