



TAP AKO -P Active Accordion System User Guide

[Home](#) » [TAP](#) » TAP AKO -P Active Accordion System User Guide 




AKO -P Active Accordion System User Guide

Contents

- [1 AKO -P Active Accordion System](#)
- [2 INSTALLATION](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)


AKO -P Active Accordion System

An professional system, made of 4 Dynamic microphones of high quality for the melodies section. Comes with 1/4 output jack that suitable to connect in amplifier and in microphone inputs of console. Include, Volume and Tone controls, along with an input (3.5 mm) for the optional bass section “AKO-B”. Suitable for amplifier and for console on microphone inputs. The clear sound covers all frequencies with a unique and warm reproduction.
Dimensions : 330mm x 60mm x 26mm



INSTALLATION

The section for the treble, installs easily over the accordion's front surface panel. The system secures on the accordion with 2 elastic round-strap brackets, that mounts on the sides. The rubber plate legs, avoids scratching on the accordion surface. The AKO-B mounts over the bass holes, with special "Velcro" tape, and connect to appropriate input (3.5 mm).





Documents / Resources

	<p>TAP AKO -P Active Accordion System [pdf] User Guide AKO -P Active Accordion System, AKO -P, Active Accordion System, Accordion System</p>
--	--

[Manuals+.](#)