

tapo C220 Security Camera User Guide

Home » tapo » tapo C220 Security Camera User Guide 🖺

Contents

- 1 tapo C220 Security Camera
- **2 Product Information**
- 3 Product Usage
- **Instructions**
- **4 DOWNLOAD APP**
- **5 SET UP**
- **6 Safety Information**
- **7 Declaration of Conformity**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



tapo C220 Security Camera



Product Information

The Tapo Security Camera is a high-quality camera that allows you to monitor your home or office remotely. It offers advanced features and easy setup through the Tapo app.

Specifications:

• Model: Tapo Security Camera

• Supported Operating Systems: iOS, Android

• App Compatibility: Tapo App

Package Contents:

- Tapo Security Camera
- User Manual

Product Usage Instructions

Step 1: Download the App

- 1. Open the App Store or Google Play Store on your mobile device.
- 2. Search for "Tapo App" and download it.

Step 2: Set Up

- 1. Launch the Tapo app on your mobile device.
- 2. Tap the button in the app and select your camera model.

3. Follow the app instructions to complete the setup process.

Please refer to the user manual for more detailed instructions and troubleshooting tips. If you encounter any technical issues or need further assistance, you can visit the <u>Tapo Support</u> website for technical support, user guides, and additional information.

Note:

Make sure to follow the safety guidelines provided in the user manual to avoid accidents or damage due to improper use of the device. Use this product with caution and at your own risk.

Compliance:

This product complies with TP-Link's standards and regulations, including TP-Link's Declaration of Conformity. For more information, please visit https://www.tapo.com/support/ce/.

DOWNLOAD APP



SET UP

Tap the button in the app and select your camera model. Follow app instructions to complete setup.

Safety Information

- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Do not use the device where wireless devices are not allowed.
- Adapter shall be installed near the equipment and shall be easily accessible.

For indoor camera

Keep the device away from water, fire, humidity or hot environments.

For outdoor camera

- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.
- Adapter should be used indoors where the ambient temperature is lower than or equal to 40°C.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant

provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863.

Declaration of Conformity

- The original EU Declaration of Conformity may be found at https://www.tapo.com/support/ce/.
- TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.
- The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca/.

Visit <u>www.tapo.com/support</u> for technical support, user guides, and more information.

Documents / Resources



tapo C220 Security Camera [pdf] User Guide C220 Security Camera, C220, Security Camera, Camera

References

- Support | Tapo
- Regulatory Compliance | Tapo
- P Regulatory Compliance | TP-Link

Manuals+