



## taurus 2000 Digital Force Ionic Instruction Manual

[Home](#) » [taurus](#) » taurus 2000 Digital Force Ionic Instruction Manual 

### Contents

- 1 taurus 2000 Digital Force Ionic Instruction Manual
- 2 SERVICE:
- 3 FOR EU PRODUCT VERSIONS AND/OR IN THE CASE THAT IT IS REQUESTED IN YOUR COUNTRY:  
ECOLOGY AND RECYCLABILITY OF THE PRODUC
- 4 Read More About This Manual & Download PDF:
- 5 Documents / Resources
  - 5.1 References

### taurus 2000 Digital Force Ionic Instruction Manual



Dear customer,

Many thanks for choosing to purchase a TAURUS brand product.

Thanks to its technology, design and operation and the fact that it exceeds the strictest quality standards, a fully satisfactory use and long product life can be assured.

Read these instructions carefully before switching on the appliance and keep them for future reference. Failure to follow and observe these instructions could lead to an accident.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Cleaning and user maintenance shall not be made by children unless they are supervised.

This appliance is not a toy. Children should be supervised to ensure that they do not play with the appliance.

If you use the appliance in a bathroom or similar place, unplug the appliance from the mains when it is not in use, even if it is only for a short while, as proximity to water involves a risk, even if the appliance is disconnected. x As an additional protection to the electrical supply for the appliance, it is advisable to have a differential current device with a maximum sensitivity of 30 mA. Ask for advice from a competent installer.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified person in order to avoid a hazard.

This appliance is for household use only, not professional, industrial use.

If any of the appliance casings breaks, immediately disconnect the appliance from the mains to prevent the possibility of an electric shock.

Do not use the appliance if it has fallen on the floor, if there are visible signs of damage or if it has a leak

Do not direct the air flow directly to the eyes.

Always make sure that there are no broken or moving parts inside the device before connecting.

**WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



This symbol means that product must not be used near water.

Ensure that the voltage indicated on the rating label matches the mains voltage before plugging in the appliance.

Connect the appliance to a socket that can supply a minimum of 10 amperes.

The appliance's plug must fit into the mains socket properly. Do not alter the plug. Do not use plug adaptors.

Do not force the power cord. Never use the power cord to lift up, carry or unplug the appliance

Do not wrap the power cord around the appliance.

Do not clip or crease the power cord

Do not allow the power cord to hang or to come into contact with the hot surfaces of the appliance.

Check the state of the power cord. Damaged or tangled cables increase the risk of electric shock.

Do not touch the plug with wet hands.

Do not use the appliance if the cable or plug is damaged.

**CAUTION:** Maintain the appliance dry.

Do not use the appliance with damp hands or feet, or when barefooted.

Supply cord should be regularly examined for signs of damage, and if the cord is damaged, the appliance must not be used.

Do not use or store the appliance outdoors.

Do not leave the appliance out in the rain or exposed to moisture. If water gets into the appliance, this will increase the risk of electric shock.

Do not use hair sprays or other spray product whilst the machine is switched on.

**CAUTION:** In order to prevent overheating do not cover the appliance.

Ensure that neither the air access nor exit become either totally or partially covered by drapery, clothing, etc., as this increases the risk of fire.

## **SERVICE:**

Any misuse or failure to follow the instructions for use renders the guarantee and the manufacturer's liability null and void.

## **ANOMALIES AND REPAIR**

Take the appliance to an authorised technical support service if problems arise. Do not try to dismantle or repair without assistance, as this may be dangerous.

FOR EU PRODUCT VERSIONS AND/OR IN THE CASE THAT IT IS REQUESTED IN YOUR COUNTRY:  
ECOLOGY AND RECYCLABILITY OF THE PRODUCT




The materials of which the packaging of this appliance consists are included in a collection, classification and recycling system. Should you wish to dispose of them, use the appropriate public containers for each type of material.

The product does not contain concentrations of substances that could be considered harmful to the environment. This symbol means that in case you wish to dispose of the product once its working life has ended, take it to an authorised waste agent for the selective collection of waste electrical and electronic equipment (WEEE).

This appliance complies with Directive 2014/35/EU on Low Voltage, Directive 2014/30/EU on Electromagnetic Compatibility, Directive 2011/65/EU on the restrictions of the use of certain hazardous substances in electrical and electronic equipment and Directive 2009/125/EC on the ecodesign requirements for energy-related products.

*Read More About This Manual & Download PDF:*

Documents / Resources

	<p><a href="#">taurus 2000 Digital Force Ionic</a> [pdf] Instruction Manual</p> <p>2000 Digital Force Ionic, 2000, Digital Force Ionic, Force Ionic, Ionic</p>
---	--

References

- [Fairway Independent Mortgage Corporation](#)
- [Fairway Independent Mortgage Corporation](#)
- [Taurus](#)
- [Taurus](#)
- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.