

taurus HD2000D Digital Force 2000 Ionic Instruction Manual

Home » taurus » taurus HD2000D Digital Force 2000 Ionic Instruction Manual



Contents

- 1 taurus HD2000D Digital Force 2000
- 2 Instructions for use
- **3 USE AND CARE**
- **4 INSTRUCTIONS FOR USE**
- **5 ACCESSORIES**
- **6 SAFETY THERMAL PROTECTOR**
- 7 Documents / Resources
 - 7.1 References





taurus HD2000D Digital Force 2000 Ionic



Digital Force 2000 Ionic HD2000D

Instructions for use





(Original instructions)

DESCRIPTION

- · A: Air & ion outlet
- B: Temperature selector (*)
- · C: Speed selector
- · D: Air inlet filter
- E: Power cord
- F: Magnetic concentrator

Temperatures:

- Blue light Cold air
- Green light Hot air 60°C
- Purple light Hot air 80°C
- Red light Hot air 100°C
- Red / blue light Hot air 100°C alternating cycles of 5 seconds of cold air
- If the model of your appliance does not have the accessories described above, they can also be bought separately from the Technical Assistance Service.

USE AND CARE

- Fully extend the appliance's power cable before each use.
- Do not use the appliance if its accessories are
- Do not use the appliance if the accessories attached to it are defective. Replace them immediately.
- Do not use the appliance if the on/off switch does not work.

- Unplug the appliance from the mains when not in use and before undertaking any cleaning task.
- Store this appliance out of reach of children and/or persons with physical, sensory or reduced mental or lack of experience and knowledge. Do not store the appliance if it is still hot.
- Make sure that dust, dirt or other foreign objects do not block the fan grill on the appliance. Keep the appliance
 in good condition. Check that the moving parts are not misaligned or jammed and make sure there are no
 broken parts or anomalies that may prevent the appliance from operating correctly.
- Never leave the appliance unattended while in use.
- Do not leave the unit running on a surface.
- Do not use the appliance to dry pets or animals. Do not use the appliance to dry textiles of any kind.

INSTRUCTIONS FOR USE

BEFORE USE:

- · Make sure that all products' packaging has been removed.
- Some parts of the appliance have been the appliance is used a light smoke may be detected. After a short time, this smoke will disappear.

USE:

- Extend the cable completely before plugging it in.
- Connect the appliance to the mains. the desired direction.
- Turn the appliance on, by using the speed selector button (C).
- Select the desired temperature.
- To improve the outcome the appliance should be used at low speed and soft power. In addition it should be kept at a distance of between 10 and 15 cm from the user head.

IONIC FUNCTION

- The appliance can generate negative ions. Once the appliance is in operation, it automatically activates the generation of negative ions.
- Negative ions are useful for removing the static electricity and hair frizz.
- COOL AIR BLOW: to shape the hair.
- To use this function, press button (B) until the light is blue.
- ONCE YOU HAVE FINISHED USING THE APPLIANCE:
- Stop the appliance using the speed selector (C). Unplug the appliance from the mains.

ACCESSORIES

- Air concentrator accessory (F):
- This accessory is used to concentrate the air
 Place the concentrator at the air outlet (A) when the appliance is switched off and has cooled down completely.

SAFETY THERMAL PROTECTOR

- The appliance has a safety device, which protects the appliance from overheating. When the appliance switches itself on and off repeatedly, for reasons other than the thermostat control, check to ensure that there are no obstacles that impede correct air entry or expulsion.
- If the appliance turns itself off and does not switch itself on again, disconnect it from the mains supply, and wait for approximately 15 minutes before reconnecting. If the machine does not start again seek authorised technical assistance.

CLEANING

- Disconnect the appliance from the mains and allow it to cool before undertaking any cleaning task.
- Clean the equipment with a damp cloth with a few drops of washing-up liquid and then dry. Do not use solvents, or products with an acid or base pH such as bleach, or abrasive products, for cleaning the appliance.
- Do not let water or any other liquid get into the air vents to avoid damage to the inner parts of the appliance.
- Never submerge the appliance in water or any other liquid or place it under running water.

CLEANING THE FILTER (FIG.1):

• The air inlet filter should be cleaned periodically for proper operation of the device. To do this, turn the filter counterclockwise. Clean the filter and remove any dirt or hair. Put the filter back in its place and turn clockwise.

COUNTRY	ADDRESS	PHONE
Algeria	Zone d'Activite, N° 62, Constantine	213770777756
Argentina	Av. del Libertador 1298,(B1638BEY), Vicente López (Pcia. Buenos Aires)	541153685223
Belgium	Mariëndonkstraat 5, 5154 EG, Elshout	31620401500
Bulgaria	265,Okolovrasten Pat, Mladost 4, 1766, Sofia	35929211120 / 35929211193
Congo (Republic of)	98 Blvd General Charles de Gaulle, Pointe Noire	242066776656
Cyprus	20, Bethlehem Str. / P.O.Box 20430, 2033, Strovolos	35722711300
Czech Republic	Milady Horakove 357/4, 568 02, Svitavy	420 461 540 130
Equatorial Guinea	SN Av Patricio Lumumba y C/ Jesus B, Bata	00240 333 082958 / 00240 333 082453
Equatorial Guinea	Calle de las Naciones Unidas, PO box 762, Malabo	240333082958 / 240333082453
España	Avda Barcelona, S/N, 25790 Oliana (Lleida) atencioncliente@taurus.es	902 118 050
France	Za les bas musats 18, 89100, Malay-le-Grand	03 86 83 90 90
Ghana	Ederick Place, Accra-Ghana	302682448 / 302682404
Gibraltar	11 Horse Barrack Lane, 54000, Gibraltar	00350 200 75397 / 00350 200 41023
Greece	Sapfous 7-9, 10553, Athens	+30 21 0373 7000
Hong Kong	Unit H,13/F., World Tech Centre, Hong kong	(852) 2448 0116 / 9197 3519
Hungary	Késmárk utca 11-13, 1158, Budapest	+36 1 370 4519
India	C-175, Sector-63, Noida, Gautam Budh Nagar - 201301, Delhi	(+91) 120 4016200
Ivory Coast	01 Rue Des Carrossiers-Zone 3, B.P 3747, Abidjan 01 (RCI)	22521251820 / 225 21 353494

Luxembourg	Mariëndonkstraat 5, 5154 EG, Elshout	31620401500
Marruecos	Big distribution society 4 Rue 13 Lot. Smara Oulfa, Casablanca	(+212) 522 89 40 21
Mauritania	134 Avenue Gamal Abdener Ilot D, Nouakchott	2225254469 / 2225251258
Mexico	Rosas Moreno Nº 4-203 Colonia de San Rafael C.P. 06470 – Delegación Cuauhtémoc, Ciudad de México	(+52) 55 55468162
Montenegro	Rastovac bb, 81400, Niksic	+382 40 217 055
Netherlands	Mariëndonkstraat 5, 5154 EG, Elshout	31620401500
Nigeria	8, Isaac; John Str,G.R.A Ikeja Lagos	23408023360099
Paraguay	Denis Roa 155 c/ Guido Spano, Asunción	21665100
Peru	Calle los Negocios 428, Surquillo, Lima	(511) 421 6047
Portugal	Avenida Rainha D. Amélia, nº12-B, 1600-677, Lisboa	+351 210966324
Romania	Dudesti Pantelimon 23, 410554, Bucharest	031.805.49.58
Serbia	Rastovac bb, 81400, Niksic	+382 40 217 055
Slovakia	Milady Horakove 357/4, 568 02, Svitavy	420 461 540 130
Southafrica	Unit 25 & 26, San Croy Office Park, Die Agora Road, Croydon, Kempton Park, 1619, Johan- nesburg	(+27) 011 392 5652
Tunisia	2, Rue de Turquie, Tunis	21671333066
Ukraine	Block 6, Ap Housing Estate Topol-2, B, 49000, Dnepropetrovsk	380563704161 / 38056370416
Uruguay	Luis Alberto de Herrera 3468, 11600, Montevideo	598 2209 28 00
Vietnam	Lot 7 Ind. Zone for, Ha Noi	84437658111 / 84437658110

www.taurus-home.com

Documents / Resources



taurus HD2000D Digital Force 2000 Ionic [pdf] Instruction Manual HD2000D Digital Force 2000 Ionic, HD2000D, Digital Force 2000 Ionic, Force 2000 Ionic, 2000 Ionic, Ionic

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.