




tc electronic Flashback 2 Delay and Looper Owner's Manual

[Home](#) » [tc electronic](#) » tc electronic Flashback 2 Delay and Looper Owner's Manual 

tc electronic

Quick Start Guide FLASHBACK 2 DELAY AND LOOPER



Visit musictribe.com to download the full manual

FLASHBACK 2 DELAY AND LOOPER

Contents

1 Controls

2 FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

3 Important information:

4 Documents / Resources

4.1 References

5 Related Posts

Controls

1. **USB** – Connects to your computer for firmware updates and TonePrint editing.
2. **Delay** – Adjusts the delay time.
3. **MASH LED** – Indicates the intensity of MASH functionality.
4. **Level** – Adjusts the level of the delay repeats.
5. **Outputs**
6. **Footswitch** – Tap footswitch to turn effect on or off. Push down and hold to engage MASH and control the selected parameter.
7. **Power** – Connect a 9 V / >100 mA power supply.
8. **Feedback** – Determines the number of delay repeats.
9. **Subdivision** – Selects between quarter note, dotted eighth note, or quarter plus dotted eighth note repetitions.
10. **Delay Type** – Select delay type or TonePrint 1-3*.
11. **Inputs**

*NO AUDIO ON TONEPRINT 3?The default TonePrint 3 setting mutes the output.
Use the MASH switch like a volume pedal to increase volume gradually.

FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

TC Electronic

FLASHBACK 2 DELAY AND LOOPER

Responsible Party Name:	Music Tribe Commercial NV Inc.
Address:	5270 Procyon Street, Las Vegas NV 89118, United States
Phone Number:	+1 702 800 8290

FLASHBACK 2 DELAY AND LOOPER

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Important information:

Changes or modifications to the equipment not expressly approved by Music Tribe can void the user's authority to use the equipment.




Hereby, Music Tribe declares that this product is in compliance with Directive 2014/30/EU, Directive 2011/65/EU and Amendment 2015/863/EU, Directive 2012/19/EU, Regulation 519/2012 REACH SVHC and Directive 1907/2006/EC.

Full text of EU DoC is available at
<https://community.musictribe.com/>

EU Representative: Music Tribe Brands DK A/S
 Address: Ib Spang Olsens Gade 17, DK – 8200 Aarhus N, Denmark



tc electronic

Documents / Resources



[tc electronic Flashback 2 Delay and Looper](#) [pdf] Owner's Manual
 Flashback 2 Delay and Looper

References

-  [Music Tribe](#)
-  [Music Tribe](#)