



[Home](#) » [TCL](#) » **T705M TCL Phone Circuit World User Guide** 

*T705M TCL Phone Circuit World User Guide*

# TCL 60<sub>XE</sub>

## NXTPAPER 5G

### QUICK START GUIDE

**English – CJB2NL0LCAAA**

**Printed in China**

#### **Contents** [ [hide](#) ]

[1 Welcome to TCL](#)

[2 Your TCL phone](#)

[2.1 Keys and connectors](#)

[2.2 Set up your TCL phone](#)

[2.3 Home screen](#)

[2.4 Messages](#)

[3 Gmail](#)

[4 Documents / Resources](#)

[4.1 References](#)

## **Welcome to TCL**

Check out the TCL website at [www.tcl.com](http://www.tcl.com) for tutorials and answers to frequently asked questions, and to download the User Manual.

## CUSTOMER SUPPORT

United States & Canada

Phone: 1-[855-224-4228](tel:855-224-4228)

Web: <https://support.tcl.com>

Update your phone's software

Go to Settings > System > System Update to check software updates.

Back up your personal data


Go to Settings > System > Backup > Back up now and turn it on.


Reset your phone

Go to Settings > System > Reset options > Erase all data (factory reset) > Erase all data.

## Your TCL phone

### Keys and connectors






## Set up your TCL phone

1. Your new phone is partially charged. Charge the battery with the included USB-C cable.

**Note:** Charger not included with your device. Refer to the Safety guide for information on compatible chargers.

2. Use the provided SIM pin to open the SIM tray.
3. Place the Nano SIM card and/or microSD™ card into the tray, then slide the SIM tray into the slot.


**Note:** microSD™ cards are sold separately. Only use Nano SIM cards with your phone.




**Caution:** Do not insert the SIM pin into the small holes on top or bottom of the phone.

## Home screen

You can bring all of the items that you use most frequently (applications, folders, widgets) to your Home screen for quick access.



Tapping Home  always takes you back to the main Home screen.




Expand your Home screen with widgets and more personalization.



Swipe down from the Status bar to view the Notification panel and access all pending notifications. Tap on the Notification to open the message.




Swipe down again to view Quick Access settings options. Tap  to access the complete Settings menu.

## Messages

Create, edit, send, and receive text (SMS) and media (MMS) messages.

A SMS will be converted to MMS automatically when media files (such as image, video, or audio) are attached, when a subject is added to the message, or an email address is used for a recipient.



1. Tap to send the text message.

Touch and hold  to record audio.

2. Touch and hold to switch language (if additional language keyboards are activated).

3. Attach a picture from the gallery or shoot one directly.

4. Insert a GIF, location, contact or other media file.

5. Tap to input a comma. Touch and hold to access keyboard settings or enter left or right hand input mode.

6. Tap to access the symbols and numbers keyboards.


## Gmail

Use Gmail to create, send, and receive emails directly on your phone. The Gmail app will allow you to add several email accounts.



1. Tap to view the email accounts on your device.
2. Tap to access email folders, settings, and more.
3. Tap to create an email

## Documents / Resources

 QUICK START GUIDE English (CHINESE/ENGLISH) Printed in China	<a href="#">TCL T705M TCL Phone Circuit World [pdf]</a> User Guide T705M, 60 XE NXTPAPER 5G, T705M TCL Phone Circuit World, T705M, TCL Phone Circuit World, Phone Circuit World, Circuit World
---	---

## References

- [User Manual](#)

TCL  
60 XE NXTPAPER 5G, Circuit World, Phone Circuit World, T705M, T705M TCL Phone Circuit World, TCL, TCL Phone Circuit World

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.