



## T799B TCL 10 pro Mobile Phone User Guide

[Home](#) » [TCL](#) » T799B TCL 10 pro Mobile Phone User Guide

# TCL 10 Pro

T799B

**QUICKSTART GUIDE**  
SAVE PAPER SAVE TREES


PLEASE CONSIDER THE  
ENVIRONMENT BEFORE PRINTING

### Your Mobile

#### Contents [ [hide](#) ]

- 1 Keys and connectors
- 2 Getting started
- 3 Home screen
- 4 Calls
- 5 Answering a call
- 6 Contacts
- 7 Messages
- 8 Gmail
- 9 General Information
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts

## Keys and connectors



<sup>(1)</sup> Customized convenient shortcut


## Getting started

- ① Your new phone is partially charged. Charge the battery by using the USB-C cable and charger provided.
- ② Use the provided SIM pin to open the SIM tray.

③ Place the Nano SIM card into the tray slot labeled “SIM”.

④ If applicable, place the microSD™ card on the opposite side of the tray slot were labeled “SD”.


Note: microSD™ cards are sold separately. Only use Nano-SIM cards with your phone.





**Caution:** Do not insert the SIM pin into the speaker on top or bottom of the phone.


## Home screen

You can bring all of the items that you use most frequently (applications, shortcuts, folders) to your Home screen for quick access.

Tapping Home  always takes you back to the main Home screen.





① Swipe down from the Status bar to view the Notification panel and access all pending notifications. Swipe down again to view Quick Access settings options.

② Tap  to access the complete Settings menu.




## Calls



### Making a call

From the Phone  app, use the keypad to enter the phone number, or the keyboard to enter the contact name. Then tap  to place the call.

### Answering a call


When you receive a call:

- Tap ANSWER, or swipe up the icon  to answer;
- Tap DECLINE, or swipe down the icon  to reject;
- Tap  to reject the call by sending a preset message.



## Contacts

Use **Contacts** to view your saved contacts or create a new contact. Synchronize your contacts from your email account(s) and other applications to your phone.




- ① Tap to search for a contact.
- ② Tap to select multiple contacts for bulk editing, such as adding a label to the contact.
- ③ Tap to view all the contacts saved on your device.
- ④ Tap on the contact name or icon to open the contact card, where you can edit their information, call them, and more. Touch and hold to share or delete the selected contact(s).
- ⑤ Tap to create a new contact.

## Messages

You can create, edit, send, and receive SMS and MMS.


An SMS will be converted to MMS automatically when media files (image, video, audio, slides, etc.) are attached when a subject is added to the message, or an email address is used for a recipient.



- ① Tap to send the SMS or MMS message.
- ② Touch and hold to switch language.
- ③ Insert a picture from the gallery or shoot one directly.
- ④ Insert a GIF, sticker, location, voice memo, contact, or another file.
- ⑤ Tap to input a comma. Touch and hold to access keyboard settings, input an emoticon, and enter left or right-hand input mode.
- ⑥ Tap to access the symbols and numbers keyboards.

## Gmail

Use Gmail to create, send, and receive emails directly on your phone. The Gmail app will allow you to add several email accounts.



- ① Tap to view the email accounts on your device.
- ② Tap to access email folders, settings, and more.
- ③ Swipe right or left to archive the email.
- ④ Tap to create an email.

## General Information


- Visit the TCL website at [tclusa.com](http://tclusa.com) for tutorials and answers to frequently asked questions, and to download the User Manual.
- To get support for your phone, visit the TCL website ([tclusa.com](http://tclusa.com)), or dial the number listed below:  
Canada- 1-855-224-4228  
United States- 1-855-224-4228
- **Update your phone's software**  
Go to **Settings > System > System updates** to check software updates.
- **Back up your personal data**  
Go to **Settings > System > Backup > Back up to Google Drive** and turn it on.
- **Reset your phone**  
Go to **Settings > System > Reset > Factory data reset > Reset phone > Erase everything**.
- **Removing your Google Account**  
Go to **Settings > Accounts > tap on the account > Remove Account**.



English – CJB66B101AAA



Documents / Resources

	<p><a href="#">TCL T799B TCL 10 pro Mobile Phone</a> [pdf] User Guide</p> <p>T799B TCL 10 pro Mobile Phone, T799B TCL 10 pro, T799B Mobile Phone, T799B</p>
---	---

References

-  [TCL USA | Enjoy More](#)