



# TCL TS6110 ALTO 6+ 2.1 Channel Soundbar with Dolby Audio and Wireless Subwoofer User Guide

[Home](#) » [TCL](#) » [TCL TS6110 ALTO 6+ 2.1 Channel Soundbar with Dolby Audio and Wireless Subwoofer User Guide](#) 

## Contents

- [1 TCL TS6110 ALTO 6+ 2.1 Channel Soundbar with Dolby Audio and Wireless Subwoofer](#)
- [2 What's in the box](#)
- [3 Overview](#)
  - [3.1 Sound Bar main unit](#)
- [4 Overview](#)
- [5 Place your Sound Bar and Subwoofer](#)
  - [5.1 Wall mount your Sound Bar](#)
- [6 Connect to your TV](#)
  - [6.1 HDMI-ARC](#)
  - [6.2 Optical](#)
  - [6.3 AUX](#)
- [7 Install or replace the Remote battery](#)
- [8 Pair with your Bluetooth device](#)
- [9 Sound Bar LED Display](#)
- [10 FAQ](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

# TCL

**TCL TS6110 ALTO 6+ 2.1 Channel Soundbar with Dolby Audio and Wireless Subwoofer**




## What's in the box

Make sure you read all the safety information before you use this product.



**Sound Bar main unit**



**Subwoofer**




**AC power cord x 2**



**Optical cable**




**HDMI cable**



**Remote control**




**AAA battery x 2**



**Wall mount bracket x 2**




**Wall anchor x 2**




**Wall mounting screw x 2**




**Quick Start Guide**



**Safety leaflet**




**Warranty card**



**Wall mount template**

## Overview

**Sound Bar main unit**




### Source button:

Press to switch the audio source among HDMI/OPT/AUX/USB/BT modes.

### Volume buttons:

Press to increase or decrease the volume level.







### Power button:


Short press to power on/off. Long press to reset to factory default

### Bluetooth button:

Press to select the Bluetooth source. Press and hold to enter pairing mode.




## Overview




## Place your Sound Bar and Subwoofer


The ideal place to position the Sound Bar is centered underneath your TV.  
For the Subwoofer to work correctly, it should be less than 9.8 feet from the Sound Bar.



## Wall mount your Sound Bar





1. Place the supplied wall mount template on the wall. Make sure the wall mount template is at least 2 inches below the center of the TV.
2. Use a level to make sure the wall mount template is positioned accurately.
3. Use the tape to stick the wall mount template firmly on the wall.
4. Mark on the wall using each marking on the template through the mounting holes.
5. Take away the wall mount template.
6. Drill a screw hole at each marking on the wall.




7. Insert the wall anchors in the holes on the wall.
8. Insert the supplied screws into the hole of the wall anchors

9. Fix and tighten the wall bracket screws on the wall, but leave a little space for hanging the brackets.



10. Unscrew the rubber cushions from the bottom of the sound bar and set them aside for potential use in the future.
11. Attach the included wall bracket mounts to the sound bar in the same holes the rubber cushions were removed from.
12. With the brackets now attached to the sound bar, pick up the sound bar and attach it to the wall screws, similar to how you would hang a picture. Make sure everything is tight.

## Connect to your TV



There are 3 ways to connect your sound bar to the TV (listed in order that we recommend): HDMI ARC (refer to 4a), Optical (refer to 4b), and AUX (refer to 4c)


For USA only: If you have a Roku TV™, simply plug in the HDMI cable and follow the Roku TV Ready™ on-screen instructions.

### HDMI-ARC

Connect the Sound Bar with your TV through the supplied HDMI cable.

Connect the Sound Bar and the subwoofer to the power supply with the supplied power cords.

## Optical




Connect the Sound Bar with your TV through the supplied Optical cable.

Connect the Sound Bar and the subwoofer to the power supply with the supplied power cords.

## AUX


Connect the Sound Bar with your TV through AUX cable (not supplied).




Connect the Sound Bar and the subwoofer to the power supply with the supplied power cords.

## Install or replace the Remote battery


**Battery type:** 1.5V AAA Alkaline battery x 2



## Using the Remote



## Pair with your Bluetooth device




You can stream music from your mobile device via Bluetooth.

1. Press Power.
2. Press Bluetooth.
3. Press and hold on the remote control or press and hold on your sound bar.
  - You hear a sound signal and blue light is flashing on the sound bar.
  - The Sound Bar is ready to pair.
4. Power on your Bluetooth device and activate its Bluetooth function.
5. Select TCL Alto 6+.
  - You hear a sound signal.
  - Pairing is successful.
6. If you want to re-pair with another device, please repeat step 3.

# Sound Bar LED Display

The LED display on the Sound Bar gives you information about the status of the Sound Bar.



## FAQ

### Does this Sound Bar work with any TV?

Yes, the Sound Bar is compatible with any TV that has one of the ports below:

1. HDMI supporting ARC (preferred)
2. Optical audio output (TOSLink)
3. Headphone output

### When the Sound Bar and TV are both on, there is an echo effect.

If you use an HDMI-ARC connection, please check if the HDMI-CEC feature of your TV is turned on. This feature may be called T-Link, Anynet+, SimpLink, BRAVIA Link, EasyLink, or VIERA Link. If using an optical or AUX connection, simply mute the TV speaker.

### How many sound modes are available?

Three sound modes – Movie, Music, and TV.

## What does the LED indicator on the subwoofer indicate during pairing?


- Standby mode: flashes slowly.
- Pairing: flashes quickly.
- Paired: on solidly.

## How to clean the soundbar?

Please keep your soundbar in a dry and ventilated environment. If it needs to be cleaned, please wipe it gently with a soft, dry cloth without water or other cleaning agents.

\*All technology names mentioned are the trademarks or registered trademarks of their respective companies.

## Documents / Resources

	<a href="#">TCL TS6110 ALTO 6+ 2.1 Channel Soundbar with Dolby Audio and Wireless Subwoofer</a> [pdf] User Guide TS6110, ALTO 6, 2.1 Channel Soundbar, Dolby Audio, Wireless Subwoofer
---	---