

TCL TS8212 8+ 2.1.2 Channel Dolby Atmos Sound Bar User Guide

Home » TCL » TCL TS8212 8+ 2.1.2 Channel Dolby Atmos Sound Bar User Guide T





User Guide

Contents


- 1 Register Your Product
- 2 What's in the box
- 3 Overview
- 4 Position your Sound Bar
- 5 Connect to your TV
- 6 Install or replace the remote

batteries

- 7 Pair with your Bluetooth device
- 8 Sound Bar LED Display
- 9 Trademarks
- 10 FAQ
- 11 Documents / Resources


Register Your Product

Register your TCL Sound Bar to receive the latest news on product releases, promotional offers, and more!*



Text to Register Text a photo of the camera icon to 71403 Or register online at <u>register.tcl.com</u> Need help? Visit <u>photoregister.com/helpor</u> text HELP to 71403


Enjoy exclusive benefits with registration:



^{*}Only Available to U.S. Customers

What's in the box

Make sure you read all the safety information before you use this product.




Overview

Sound Bar main unit


⊙ ⊕ * − +


TCL



- 1. AC input power connector
- 2. HDMI IN connector
- 3. HDMI ARC connector
- 4. Optical input connector
- 5. USB Type A connector


Wireless subwoofer






Position your Sound Bar


The ideal place to position the Sound Bar is centered underneath your TV.




Wall mount your Sound Bar Required tools:



- 1. Place the supplied wall mount template on the wall. Make sure the wall mount template is at least 2 inches below the center of the TV.
- 2. Use a level to make sure the wall mount template is positioned accurately
- 3. Use the tape to stick the wall mount template firmly on the wall.
- 4. Mark on the wall using each marking on the template through the mounting holes.
- 5. Take away the wall mount template.
- 6. Drill a screw hole at each marking on the wall.




- 7. Insert the wall anchors in the holes on the wall.
- 8. Insert the supplied screws with the sleeves into the hole of the wall anchors.
- 9. Fix and tighten the wall bracket screws on the wall.




Required tools: \$

- 10. Unscrew the rubber cushions from the bottom of the sound bar and set them aside for potential use in the future.
- 11. Attach the included wall bracket mounts to the sound bar in the same holes the rubber cushions were removed from.



12. With the brackets now attached to the sound bar, pick up the sound bar and attach it to the wall screws, similar to how you would hang a picture. Make sure everything is tight.



Connect to your TV

There are 2 ways to connect your sound bar to the TV (listed in order that we recommend): HDMI ARC (refer to 5a and 5b), and Optical (refer to 5c).


For USA only: If you have a Roku TVTM , simply plug in the HDMI cable to the ARC ports and follow the Roku TV Ready TM on-screen instructions.



Simple setup One remote Quick settings

HDMI-ARC


Connect the Sound Bar with your TV through the supplied HDMI cable. Connect the Sound Bar to the power supply with the supplied power cord.



HDMI-ARC

Enable CEC function on TCL TV.

- 1. Connect HDMI cable from the HDMI (ARC) interface on the sound bar to the HDMI (ARC/eARC) interface on the TV.
- 2. Connect power cord. Enable the T-Link function in the settings of the TCL TV.



Enable CEC function on other brand TV.


- 1. Connect HDMI cable from the HDMI (ARC) interface on the sound bar to the HDMI (ARC/eARC) interface on the TV.
- 2. Connect power cord.

Enable the CEC function in the settings of the TV.

Note:


CEC function naming may differ by TV manufacturer.

This feature may be called T-Link, Anyone+, Sump Link, BRAVIA Link, Easylink or VIERA Link. Please see your TV's user manual for more information.




Optical

Connect the Sound Bar with your TV through the supplied Optical cable. Connect the Sound Bar to the power supply with the supplied power cord.



Install or replace the remote batteries

Battery type: 1.5V AAA Alkaline battery x 2



1.

Press to enter Standby mode.

- 2. Press to adjust the brightness of the display. Press and hold for 2 seconds to enter Night mode.
- 3. SURR

Press to turn on/off Dolby vertical surround.

4. OPT

Press to switch the audio source to Optical mode.

5. HDMI IN

Press to switch the audio source to HDMI IN mode.

6. HDMI ARC

Press to switch the audio source to HDMI OUT (ARC) mode.

7. USB

Press to switch the audio source to USB source.

8. *

Press to switch the audio source to Bluetooth mode.

Press and hold to enter pairing mode.

- 9. Press to switch on/off Pass Through function.
- 10. MOVIE / MUSIC / TV

Press to select the equalizer (EQ) effect when you are watching TV, movie or listening to music.

11. TREBLE


Increase or decrease the treble sound effect.

- 12. Switch to previous or next music. (Under Bluetooth or USB mode) Decrease or increase the volume level.
- 13. dat/ox Press to play/pause the music. (Under Bluetooth or USB mode)

In Standby mode or Sleep mode, press and hold for 5 seconds to enter Menu, and then press to view options. Press OK to confirm.

- 14. Press to mute or unmute the sound.
- 15. Bass


Increase or decrease the bass sound effect.



Pair with your Bluetooth device

You can stream music from your mobile device via Bluetooth.


- 1. Press.
 - 2. Press.
 - 3. Press and hold on the remote control or press and hold on your sound bar.
 - > You hear a sound signal.
 - > The Sound Bar is ready to pair.
- 2. Power on your Bluetooth device and activate its Bluetooth function.
- 3. Select TCL 8212 Sound Bar.
 - > You hear a sound signal.
 - > Pairing is successful.
- 4. If you want to re-pair with another device, please repeat step 3.



Sound Bar LED Display

The LED display on the Sound Bar gives you information about the status of the Sound Bar.





Remote Contro	LED Indications	Remarks
	HELLO START READY STOBY	*Power on/off
OPT HDMIN ARC USB PASS THRU PAIRING	OPT (HDMI 1 IN (HDMI 2 ARC) USB (BT)(PAIR (CONNECTED) PRSS THROUGH	*Input source *Connect your Blu-ray player via HDMI IN to use PASS THR U
MOVIE MUSIC TV	(MOVIE) [MUSIC] [TV]	Set preferred sound
où 2s → NIGHT	NIGHT	Reduced dynamics
SURR	SURR ON/OFF	Enhanced surround effect
TREBLE TREBLE BASS BASS BASS	TRE -3 TRE +3	Increase or decrease treble or bass level
A V	(V 28) (V MAX) (V MIN) MUTE	Volume Mute/unmute
< > (bill/ok)	PAUSE	Previous, next music or pause on USB mode
- NIGHT	DIM 1 DIM 2	Set display brightness
	X	Not support
	SUB PAIR SUB CONNECTED	Pair your subwoofer manually
	DOLBY ATMOS DOLBY SURROUND	Audio format detected

Trademarks

Licensing Corporation.

Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2021 Dolby Laboratories. All rights reserved.

FAQ

Does this Sound Bar work with any TV?

Yes, the Sound Bar is compatible with any TV that has one of the ports below: 1. HDMI supporting ARC (preferred) 2. Optical audio output (TOSLink)

When the Sound Bar and TV are both on, there is an echo effect.

If you use HDMI-ARC connection, please check if the HDMI-CEC feature of your TV is turned on. This feature may be called T-Link, Anynet+, SimpLink, BRAVIA Link, EasyLink or VIERA Link. If using optical connection, simply mute the TV speaker.

How many sound modes are available?

Four sound modes - Movie, Music, TV and Night.

What are the subwoofer LED indicator status during pairing:

• Standby mode: flashes slowly. • Pairing: flashes quickly. • Paired: on solidly.

What's PASS THROUGH?

Pass through function equals to the extending of HDMI IN, which switches on/off singular source of sound passing through from the Audio / Vision device to the TV.

All technology names mentioned are the trademarks or registered trademarks of their respective companies.

DO NOT RETURN TO STORE

WE ARE READY TO HELP sith any questions



1-877-300-9223

TAKE CARE WHEN REMOVING THE SOUND BAR





Roku TV, Roku TV Ready, and the Roku TV Ready log o are trademarks of Roku, Inc.

The Adopted Trademarks HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Admin istrator, Inc. in the United States and other countries.



Dolby Atmos

The Bluetooth® word mark and logos are registered tr ademarks owned by Bluetooth SIG, Inc. and any use of such marks by TTE Corporation is under license. Ot her trademarks and trade names are those of their res pective owners. Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012-2021 Dolby Laboratories. All rights reserved.

Copyright © 2021 TCL.
All rights reserved.
TS8212_NA_USA_QSG_V0.10

Documents / Resources



TCL TS8212 8+ 2.1.2 Channel Dolby Atmos Sound Bar [pdf] User Guide
TS8212 8 2.1.2 Channel Dolby Atmos Sound Bar, TS8212, 8 2.1.2 Channel Dolby Atmos Sound Bar, Channel Dolby Atmos Sound Bar, Atmos Sound Bar, S

Manuals+,