



TECNO CAMON 12 User Manual

[Home](#) » [TECNO](#) » TECNO CAMON 12 User Manual

Contents [hide]

- [1 TECNO CAMON 12](#)
- [2 Know your phone](#)
- [3 SIM/SD card installation](#)
- [4 Charging the phone](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

TECNO

TECNO CAMON 12




Mobile Phone

Model CC7

Hereby, TECNO MOBILE LIMITED declares that this Mobile Phone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

Know your phone



1. Front camera
2. Volume key
3. Power key

SIM/SD card installation



1. Power off mobile.
2. Refer to the following picture for SIM / SD card installation.

Charging the phone




You can charge your device using a charger or by connecting it to the computer using a USB cable (comes with the phone).

1. Please remind the front and back of the plug.
2. Use only TECNO charger and cables. Other chargers or cables may damage the device. This will invalidate your phone warranty.



Documents / Resources

| | |
|--|---|
|  A thumbnail image of the TECNO CAMON 12 User Manual. It features the TECNO logo at the top left, followed by the text "CAMON 12" in a large, bold, sans-serif font. Below this, there are three small buttons labeled "User Manual", "FAQs", and "Troubleshoot". The letter "A" is located at the bottom right of the thumbnail. | <p>TECNO CAMON 12 [pdf] User Manual CAMON 12</p> |
|--|---|