




TECWARE Neo M2 Mid Tower ARGB Case User Manual

[Home](#) » [TECWARE](#) » TECWARE Neo M2 Mid Tower ARGB Case User Manual 



Neo M2 Mid Tower ARGB Case



Quick Start Guide


Contents

- [1 Specifications](#)
- [2 Front Cover](#)
- [3 Component List](#)
- [4 Motherboard Installation](#)
- [5 Package Contents](#)
- [6 Warranty](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

Specifications

Type	Specification
Motherboard Support	ITX, mATX
Dimensions	365(L) x 216(W) x 405(H) mm
3.5" HDD Drive Bay	2
2.5" SSD Drive Bay	2
Expansion Slots	4
Maximum GPU Length	330mm
Maximum PSU Length	160mm
Maximum CPU Cooler Height	175mm

Front Cover




Open the front cover by pulling outwards to the right.

Front Panel I/O Connections


BUTTONS AND ACTIVITY LIGHTS

These cables are connected to the motherboard for the power button (power sw), reset button, HDD LED, and power LED (P+ / P-).




HD AUDIO

This connector attaches to your sound card or motherboard and is used to provide the front panel mic input and headphone output.









USB 3.0 CONNECTOR


This cable connects to the USB 3.0 header on the motherboard to enable the front USB 3.0 ports.




Component List

VISUAL	ITEM	QTY	APPLICATION
A 	Motherboard & SSD screw	23	Motherboard and 2.5 hard drive installation
B 	Motherboard standoff	3	Motherboard installation
C 	HDD mount screw	8	3.5 hard drive installation
D 	PSU & Rear expansion slot screw	7	Power supply installation Mounting of GPU and other expansion cards
E 	Radiator Fan Screw	8	Radiator/Fan Installation
F 	Cable Tie	6	Cable management


Motherboard Installation




SSD Installation



GPU & PSU Installation



CUP Cooler / Fan & Radiator Installation



Package Contents

- 1 x TECWARE Neo M2 Case
- 1 x Accessories Box

Warranty

- 1 Year. Please contact your local distributor for support.



www.tecware.co

Documents / Resources



[TECWARE Neo M2 Mid Tower ARGB Case](#) [pdf] User Manual

Neo M2 Mid Tower ARGB Case, Neo M2 Mid Tower ARGB Case, Mid Tower ARGB Case, AR GB Case, Case