



# TECWARE Veil80 Wireless Mechanical Keyboard User Guide

[Home](#) » [TECWARE](#) » TECWARE Veil80 Wireless Mechanical Keyboard User Guide 

## Contents

- [1 TECWARE Veil80 Wireless Mechanical Keyboard](#)
- [2 Fn Shortcut Keys](#)
- [3 Connectivity switch](#)
- [4 Wireless Connection](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

# TECWARE

## TECWARE Veil80 Wireless Mechanical Keyboard



## Fn Shortcut Keys

1. **Fn + 't**  
LED Brightness Up
2. **Fn + ,l.**  
LED Brightness Down
3. **Fn + →**

Speed up light mode

4. **Fn + +/-**

Slow down light mode

5. **Fn + Right Shift**

Toggle Power Saving Mode (all lights out)

6. **Fn + Esc**

Switch from Light Mode/ Single Color Mode

7. **Fn + Backspace**

Toggle Backlights On / Off

8. **Fn + Enter**

Change Backlight Color

9. **Fn + II**

Change Lighting Modes (14 modes)

10. **Fn + M**

Hold down for 2 sec, Spacebar will blink twice to go into MAC mode Spacebar will blink once to goto Windows mode

11. **Fn + F**

On Mac Mode, switch the multimedia key to the standard key for the F keys

12. **Fn + I**

Insert

13. **Fn + C**

Open My Computer

14. **Fn + P**

Printscreen

15. **Fn + L**

Open Browser

16. **Fn + PgUp**

Home

17. **Fn + PgDn**

End

18. **Fn + Winkey**

Win key lock

19. **Fn + 5**

Switch to wired mode

20. **Fn + F10**

Toggle Mute

21. **Fn + F11**

Volume Down

22. **Fn + F12**

Volume Up

23. **Restore Default**

Hold down 3 sec (ESC, Left CTRL, F12, Right arrow)

## **Connectivity switch**

located at the back of the keyboard along with USB Dongle) Toggle On/Off for Wireless mode I Wired mode.

## Wireless Connection

( Connect/Store up to 3 BT Devices+ 2.4g mode)

- Long press ( 3 sec ) for pairing mode between the BT device. The corresponding number Key will blink fast when discoverable. The Key will stop blinking when paired.
- Single press to connect disconnect to the paired device. The corresponding number key will stop blinking when the connection is established.
- Single press to switch to 2.4g mode and connect the USB Dongle. The corresponding number key will stop blinking when the connection is established.

**Lighting Sleep/Time out:** ( 2 min or No time out )

Fn + Tab key to change the Sleep/Time out duration setting The Caps lock key will serve as an indicator and will blink once for 2min, twice for No time out.

**Battery Indicator:** F12 Key light color

Breathing Red light is Low Battery. Breathing Green light is Charging. Light will go back to normal when full charged.

## Documents / Resources



[TECWARE Veil80 Wireless Mechanical Keyboard](#) [pdf] User Guide

Veil80, Wireless Mechanical Keyboard, Wireless Keyboard, Mechanical Keyboard, Veil80, Keyboard