




[Home](#) » [THE HOME DEPOT](#) » **The Home Depot 8065A63F Element Smart Wi-Fi Enabled Convection Instructions** 

## Contents [ [hide](#) ]

- [1 The Home Depot 8065A63F Element Smart Wi-Fi Enabled Convection.](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Description](#)
- [5 FAQs](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)



## The Home Depot 8065A63F Element Smart Wi-Fi Enabled Convection.



## Specifications

- **Capacity:** 6.3 cu ft oven
- **Cooktop:** Smooth ceramic glass with 5 burners — includes dual-ring burners and a 3,300 W Rapid Boil element
- **Convection Oven:** Yes, includes fan-assisted bake and roast features for quicker and more even cooking
- **Air Fry:** Built-in “No-Preheat Air Fry” mode — crispy results with little to no oil; Air Fry tray sold separately
- **Smart Connectivity:** Wi-Fi & voice control via SmartThings, Alexa, Google Assistant, or Bixby allows remote monitoring and control
- **Cleaning:** Self-clean (high-heat) and Steam Clean options available
- **Preset Functions:** Includes Bread Proof, Dehydrate, Keep Warm, and Favourite Cook settings
- **Finish:** Fingerprint-resistant stainless steel
- **Control & Display:** Touch and knob controls, discretionary preset functions; ice-blue display
- **Dimensions** (approx.): 30" W × 28.7" D × 46.6–47.1" H (adjustable height)
- **Power Requirements:** 240 V / 40 A circuit typically required

## Product Usage Instructions

1. **Assembly:** Follow the provided assembly instructions carefully to set up the product.
2. **Usage:** Ensure the product is used according to the user manual to avoid voiding the warranty.
3. **Cleaning:** Clean the product regularly using a mild detergent and a soft cloth. Avoid abrasive cleaners.
4. **Maintenance:** Regularly check for any loose parts or signs of wear and tear. Replace any damaged components promptly

## Description



Elevate the look of your kitchen with Samsung's new Smart Freestanding Electric Range. Our Stainless Steel design elegantly wraps around cooktop sides and up through the slim control panel. Upgraded technology makes cooking simple and fun.

- Our Stainless Steel design elegantly wraps around cooktop sides and up through the slim control panel, elevating the look of any kitchen
- No preheat. Air Fry is a healthier way to prepare your favourite fried foods right in your oven with little to no oil. Air Fry tray not included. As compared to deep frying
- Wi-Fi and Voice Enabled allows you to preheat, monitor and adjust the time and temperature of your oven from wherever you are using your smartphone
- Powerful Convection+ saves you time by cooking food fast and more evenly
- Large 6.3 cu. A ft. oven can fit multiple dishes at one time, and can easily accommodate big casserole dishes and large roasting pans
- Boil water fast with the 3300-Watt Rapid Boil burner
- Fingerprint-resistant for an everyday beautiful finish
- 5-burner cooktop includes adjustable medium and large dual-ring burners

- Prepare foods with the aid of easy preset buttons, 4 preset buttons include: Bread Proof, Dehydrate, Keep Warm and Favourite Cook
- Samsung's SmartThings Cooking service makes meal planning a seamless process. Search, plan, purchase and prep weekly meals via the SmartThings app on your Family Hub or smartphone. Available on Android or IOS devices. A Wi-Fi connection and a Samsung account are required
- Keep your oven spotless with the Self and Steam Clean
- 30"W x 28.6"D x 46.6"H

## **Safety Instructions**

### **1. Professional Installation**

- Ensure the oven is installed on a properly grounded 240 V / 40 A circuit by a licensed electrician.
- Install the provided anti-tip bracket to prevent accidental tipping

### **2. Hot Surface Awareness**

- The cooktop and front panel may become hot during and after use. Use caution and keep children away from hot surfaces.

### **3. Air Fry and Convection Use**

- Use only metal or heat-resistant bakeware rated for high temperatures. Avoid plastic, especially in Air Fry mode.

### **4. Cleaning Safety**

- For self-cleaning cycles, remove any cookware and ensure proper ventilation.
- Ventilate the kitchen area to avoid heat buildup or smoke during cleaning.

### **5. Smart & Remote Operations**

- Only preheat or adjust the oven remotely when you can monitor it. Use SmartThings safely—never leave the oven unattended.

### **6. Electric Safety**

- Turn off the circuit breaker before servicing or cleaning.
- Do not attempt to repair internal components unless you're qualified.

## **Warranty Information**

- This warranty covers manufacturing defects and workmanship under normal use

conditions. It does not cover damage caused by misuse, accidents, or unauthorised repairs.

- To make a warranty claim, retain the original sales receipt and contact our after-sales service team at [BonnieWalpole1@outlook.com](mailto:BonnieWalpole1@outlook.com).

FAQs


Q: What does the warranty cover?

A: The warranty covers manufacturing defects and workmanship under normal use conditions.

Q: What is not covered by the warranty?

A: The warranty does not cover damage from misuse, accidents, unauthorised repairs, or use outside of a single-family home.

Documents / Resources

	<p><a href="#">The Home Depot 8065A63F Element Smart Wi-Fi Enabled Convection [pdf] Instructions</a></p> <p>8065A63F Element Smart Wi-Fi Enabled Convection, 8065A63F, Element Smart Wi-Fi Enabled Convection, Wi-Fi Enabled Convection, Enabled Convection</p>
---	---

References

- [User Manual](#)

THE HOME  
DEPOT

8065A63F, 8065A63F Element Smart Wi-Fi Enabled Convection, Element Smart Wi-Fi Enabled Convection, Enabled Convection, THE HOME DEPOT, Wi-Fi Enabled Convection

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.