



[Home](#) » [THE HOME DEPOT](#) » **The Home Depot Console Table User Manual** 

Contents [[hide](#)]

- [1 The Home Depot Console Table](#)
- [2 Specifications](#)
- [3 General Use](#)
- [4 Care Instructions](#)
- [5 Safety Tips](#)
- [6 Troubleshooting](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



The Home Depot Console Table



Specifications

- Multi-functional console table
- Two drawers for storage
- Open the lower shelf for additional storage
- Top surface weight capacity: up to 40 lbs
- Lower shelf weight capacity: up to 20 lbs

General Use

- **Multi-Functional Use:** This console table can be used as a console table, side table, or decorative storage unit. It is designed to fit seamlessly into various spaces such as living rooms, entryways, and hallways.
- **Storage:** Use the two drawers to store small items like keys, wallets, or other accessories. The open lower shelf is ideal for storing baskets, books, or decorative items to keep your space organized while maintaining its aesthetic appeal.
- **Weight Capacity:** The table can support moderate weight on the top surface (up to 40 lbs) and the lower shelf (up to 20 lbs). Please avoid placing excessively heavy items that may cause strain on the structure.

Care Instructions

- **Cleaning the Surface:** To clean the table, use a soft, dry cloth or a damp cloth with a mild detergent solution. Wipe the surface gently to avoid scratches. Avoid using

abrasive cleaners that may damage the finish or cause discoloration.

- **Prevent Scratches:** For extra protection, consider using felt pads under hard or heavy objects to prevent scratches on the surface. Avoid placing hot objects directly on the table to prevent damage to the wood veneer and glaze.
- **Polishing:** For a shine refresh, use a wood polish formulated for veneer or wood surfaces. Apply a small amount to a soft cloth and gently buff the surface.
- **Avoid Excessive Moisture:** Avoid placing the table in high-humidity areas, as Prolonged exposure to moisture may affect the wood veneer and finish.
- **Storage:** If you need to store the table for a longer period, ensure it is placed in a dry, cool area away from direct sunlight, which may cause fading or warping of the wood.

Safety Tips

- **Ensure Stability:** The table is designed to be stable, but please make sure it is level when positioned in your space to avoid any risk of tipping.
- **Avoid Overloading:** To maintain the integrity of the design, avoid overloading the drawers or placing excessive weight on the lower shelf.
- **Child and Pet Safety:** Keep the table out of reach of small children and pets; sharp corners may pose a risk of injury.

Troubleshooting

If the drawers do not open smoothly, check for any obstruction in the drawer tracks. Gently remove any blockages, and if necessary, adjust the drawer alignment to ensure smooth movement. If the table appears wobbly: Make sure all screws and fasteners are properly tightened. If adjustments are needed, follow the assembly instructions to ensure proper alignment.

Documents / Resources

<div>Use and Care Manual</div> <div>Read the manual before using the product. It contains important information about the product's features, safety, and proper use. It also includes instructions for cleaning and maintenance. Please read the manual carefully before using the product.</div>	<div>The Home Depot Console Table [pdf] User Manual</div> <div>Console Table, Console, Table</div>
--	--

References

- [User Manual](#)

THE HOME
DEPOT

Console, CONSOLE TABLE, table, THE HOME
DEPOT

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.